Copyright

Fujitsu PC Corporation has made every effort to ensure the accuracy and completeness of this document. However, as ongoing development efforts are continually improving the capabilities of our products, we cannot guarantee the accuracy of the contents of this document. We disclaim liability for errors, omissions, or future changes.

Fujitsu, the Fujitsu logo, and LifeBook are registered trademarks of Fujitsu Limited.

The following are registered trademarks of Microsoft Corporation: MS, MS-DOS, Windows.

PCMCIA is a trademark of the Personal Computer Memory Card International Association.

Intel and Pentium are registered trademarks of Intel Corporation or its subsidiaries in the United States and other countries.

Adobe Acrobat Reader is a registered trademark of Adobe System Inc.

EarthLink is a registered trademark of EarthLink Network, Inc.

Quicken® is a registered trademark of Intuit, Inc.

Sony MiniDisc and Memory Stick are trademarks of Sony Electronics, Inc.

MOBILITY and RADEON are trademarks of ATI Technologies, Inc.

Philips is a trademark of Koninklijke Philips Electronics N.V.

PowerQuest and Drive Image are registered trademarks of PowerQuest Corporation.

Netscape 6 is a registered trademark of Netscape Communications Corporation.

McAfee is a registered trademark of Network Associates/ McAfee.com, Inc.

WinDVD is a trademark of InterVideo, Inc.

The DVD player found in some models of the LifeBook notebook incorporates copyright protection technology that is protected by method claims of certain U.S. patents and other intellectual property rights owned by Macrovision Corporation and other rights users. Use of this copyright protection technology must be authorized by Macrovision Corporation, and is intended for home and other limited viewing uses only unless authorized by Macrovision Corporation. Reverse engineering or disassembly is prohibited.

Dolby Headphone manufactured under license from Dolby Laboratories. "Dolby", "Pro Logic", and the double-D symbol are trademarks of Dolby Laboratories. Copyrights 1992-1999 Dolby Laboratories. All rights reserved.

All other trademarks mentioned herein are the property of their respective owners.

© Copyright 2002 Fujitsu PC Corporation. All rights reserved. No part of this publication may be copied, reproduced, translated, stored or transmitted in any electronic form without the written consent of Fujitsu PC Corporation.

B5FH-6531-01EN-00



DECLARATION OF CONFORMITY

according to FCC Part 15

Responsible Party Name: Fujitsu PC Corporation
Address: 5200 Patrick Henry Drive

Santa Clara, CA 95054

Telephone: (408) 982-9500

Declares that product: Model Configurations: LifeBook C2210 notebook

complies with Part 15 of the FCC Rules.

This device complies with Part 15 of the FCC rules. Operations are subject to the following two conditions:

(1) This device must not be allowed to cause harmful interference, (2) This device must accept any interference received, including interference that may cause undesired operation.

Fujitsu LifeBook® C Series notebook

Table of Contents

1	Keyboard Using the Keyboard
PREFACE	Numeric Keypad 15
	Windows Keys
Preface About This Guide	Function Keys
Fujitsu Contact Information	Volume Control
,	Controlling the Volume
2	Touchpad Pointing Device
_	Clicking 18 Double-Clicking 18
GETTING TO KNOW	Dragging
YOUR COMPUTER	Scrolling
Overview	Touchpad Control Adjustment
Unpacking	LifeBook Application Panel
	Selector Switch
Locating the Controls	Application Launch Media Player Buttons 20
and Connectors	Configuring your LifeBook Application Panel 20
Top and Front Components 8	Using the Media Player 21
Left-Side Panel Components	Desktop Control Panel
Right-Side Panel Components	
Bottom Components	3
Status Indicator Panel	GETTING STARTED
Power Indicator	
AC Adapter Indicator	Power Sources
Battery Level Indicator	Connecting the Power Adapters 25
Battery Charging Indicator	Diagles Devel
Media Player Access Indicator	Display Panel
Floppy Drive Access Indicator	Opening the Display Panel
PC Card Access Indicators	Adjusting Display Panel Brightness
NumLk Indicator	Closing the Display Patien
CapsLock Indicator	
Scri k Indicator 14	

Starting Your LifeBook NotebookPower On27Boot Sequence27BIOS Setup Utility27Booting the System28Windows Product Activation28Registering Your LifeBook notebook29Installing Click Me!29	Optical Digital Audio Out Connecting an Optical Digital Cable
-	Installing a Memory Upgrade Module45
Power Management	Removing a Memory Upgrade Module 46
Suspend/Resume/Power On Button	Checking the Computer Recognition of New Memory Capacity
Hibernation (Save-to-Disk) Feature	Device Ports
Display Timeout	Modem (RJ-11) Telephone Jack
Windows Power Management	Internal LAN (RJ-45) Jack
Restarting the System	IEEE 1394 Port
Power Off	Universal Serial Bus Port
	Parallel Port
A	Microphone Jack47
4	Optical Digital Audio-Out Connector 48
LICED INICTALL ADLE FEATURES	Headphone Jack
USER-INSTALLABLE FEATURES	S-Video Out Port 48 External Monitor Port 48
Lithium ion Battery	Serial Port
Recharging the Batteries	Infrared Port
Internal Floppy Disk Drive	5
Loading a Disk37	_
Ejecting a Disk37	USING THE INTEGRATED
Preparing a Disk for Use	WIRELESS LAN
Madia Blaver Drive	FCC Regulatory Information
Media Player Drive	Before Using This Device
Media Player Software	Connecting Windows 2000 Systems
Loading Media on Your Drive	Network Connection: Windows 2000
Using the Media Player Software39	Troubleshooting
Using Dolby™ Headphone	About IP Addresses
Using the Media Player on Battery Power 40	Specifications
Auto Insert Notification Function	•
Memory Stick/Secure Digital Slot Installing Memory Stick/SD Cards	

6	8
TROUBLESHOOTING	SPECIFICATIONS
Troubleshooting Fujitsu Service Assistant	Specifications Configuration Label

1 Preface

LifeBook C Series Notebook

Preface

ABOUT THIS GUIDE

The LifeBook® C Series notebook from Fujitsu is a powerful notebook computer. It is powered by a fast Mobile Intel® Pentium® 4 processor, has a large built-in color display, and brings the computing power of desktop personal computers (PCs) to a portable environment.

This manual explains how to operate your LifeBook notebook's hardware and built-in system software.

Your LifeBook notebook comes with Microsoft® Windows XP Home, Windows XP Professional, or Windows 2000 pre-installed.

The LifeBook notebook is a completely self-contained unit with an active-matrix (TFT) color LCD display. It has a powerful interface that enables it to support a variety of optional features.

Conventions Used in the Guide

Keyboard keys appear in brackets. Example: [Fn], [F1], [ESC], [ENTER] and [CTRL].

Pages with additional information about a specific topic are cross-referenced within the text.

Example: (See page xx.)

On screen buttons or menu items appear in bold Example: Click **OK** to restart your notebook computer.

DOS commands you enter appear in Courier type. Example: Shut down the computer?



POINT

The point icon highlights information that will enhance your understanding of the subject material.



CAUTION

The caution icon highlights information that is important to the safe operation of your computer, or to the integrity of your files. Please read all caution information carefully.



WARNING

The warning icon highlights information that can be hazardous to either you, your LifeBook notebook, or your files. Please read all warning information carefully.

FUJITSU CONTACT INFORMATION

Service and Support

You can contact Fujitsu Service and Support in the following ways:

- Toll free: 1-800-8Fujitsu (1-800-838-5487)
- Fax: 1-901-259-5700
- E-mail: 8fujitsu@fujitsupc.com
- Web site: http://www.fujitsupc.com

Before you place the call, you should have the following information ready so that the customer support representative can provide you with the fastest possible solution:

- Product name
- Product configuration number
- Product serial number
- Purchase date
- Conditions under which the problem occurred
- Any error messages that have occurred
- Hardware configuration
- Type of device connected, if any

Fujitsu Online

You can go directly to the online Fujitsu product catalog for your LifeBook notebook by clicking on the LifeBook Accessories web site URL link, located in the Windows Start menu.

You can also reach Fujitsu Service and Support on-line by clicking on the Fujitsu Service and Support web site URL link, located in the Service and Support Software folder of the Windows Start menu.



POINT

You must have an active internet connection to use the online URL links.

WARRANTY

Your LifeBook notebook is backed by a one year International Limited Warranty. Check the service kit that came with your LifeBook notebook for warranty terms and conditions.

LifeBook C Series Notebook - Section One

2 Getting to Know Your Computer

_ LifeBook C Series Notebook - Section Two




Figure 2-1 LifeBook C Series notebook (15" model shown)

Overview

This section describes the components of your LifeBook notebook. We strongly recommend that you read it before using your notebook – even if you are already familiar with notebook computers.

UNPACKING

When you receive your LifeBook notebook, unpack it carefully, and compare the parts you have received with the items listed below.

For a Pre-configured model you should have:

- LifeBook C Series notebook (Figure 2-1)
- Lithium ion battery, pre-installed
- AC adapter with AC power cord (*Figure 2-2*)
- Phone/Modem (RJ-11) telephone cable
- Drivers and Applications CD
- Fujitsu Service Assistant CD
- Getting Started Guide
- User's Guide (this document)
- Premium Care registration card and envelope
- International Limited Warranty Brochure
- Microsoft-associated product materials

Depending upon the configuration of your notebook, you may have also received the following items:

- DVD and CD-RW Application CD
- DVD Application CD
- An additional main battery

Once you have checked and confirmed that your LifeBook notebook system is complete, read through the following pages to learn about all of your notebook's components.



POINT

Detailed specifications about your LifeBook notebook can be found in the chapter entitled "Specifications" on page 91.




Figure 2-2 Typical AC Adapter




Figure 2-3 LifeBook notebook with display open (15" model shown)

Locating the Controls and Connectors

TOP AND FRONT COMPONENTS

The following is a brief description of your LifeBook notebook's top and front components. (*Figure 2-3*)

Display Panel Latch

The display panel latch locks and releases the display panel.

Display Panel

The display panel is a color LCD panel with back lighting for the display of text and graphics. (See Display Panel on page 26 for more information.)

Closed Cover Switch

The closed cover switch suspends the system when the cover is closed.

LifeBook Application Panel

The LifeBook Application Panel allows you to either launch your favorite applications by the touch of a button or to use as a media player when your unit is on. (See LifeBook Application Panel on page 20 for more information.)

Status Indicator Panel

The Status Indicator Panel displays symbols that correspond with a specific component of your LifeBook notebook. (See Status Indicator Panel on page 13 for more information.)

Suspend/Resume/Power On Button

The Suspend/Resume/Power On button allows you to suspend notebook activity without powering off, resume your notebook from suspend mode, and power on your notebook when it has been shut down from Windows. (See Suspend/Resume/Power On Button on page 30 for more information.)

Stereo Speakers

The built-in boxless dual speakers allow for stereo sound.

Keyboard

A full-size keyboard with dedicated Windows keys. (See Keyboard on page 15 for more information.)

Touchpad Pointing Device/Scroll Button

The Touchpad pointing device is a mouse-like cursor control with three buttons (left, right, and scroll buttons). (See Touchpad Pointing Device on page 18 for more information.)




Figure 2-4 LifeBook notebook left-side panel

LEFT-SIDE PANEL COMPONENTS

The following is a brief description of your LifeBook notebook's left-side components. (*Figure 2-4*)

Modem (RJ-11) Telephone Jack

The Modem (RJ-11) telephone jack is for attaching a telephone line to the internal 56K modem. (See Modem (RJ-11) Telephone Jack on page 47 for more information.)

POINT

- The internal modem is designed to the ITU-T V.90 standard. Its maximum speed of 53000bps is the highest allowed by FCC, and its actual connection rate depends on the line conditions. The maximum speed is 33600bps at upload.
- The internal modems on all LifeBook notebooks from are certified for use in the United States and Canada. The modem may be certified in other countries.

WARNING

The internal modem is not intended for use with Digital PBX systems. Do not connect the internal modem to a Digital PBX as it may cause serious damage to the internal modem or your entire LifeBook notebook. Consult your PBX manufacturer's documentation for details. Some hotels have Digital PBX systems. Be sure to find out BEFORE you connect your modem.

S-Video Out Port

The S-Video output is used to transmit a higher resolution video signal to a compatible TV or VCR. (See S-Video Out Port on page 48 for more information.)

Memory Stick/SD Card Slot

The Memory Stick/Secure Digital (SD) slot allows you to install a flash memory card for data storage. This architecture allows you to transfer data between a variety of different digital devices. (See Installing Memory Stick/SD Cards on page 42 for more information.)

Anti-theft Lock Slot

The anti-theft lock slot allows you to attach an optional physical lock-down device.

PC Card Slots

The PC Card Slots allow you to install two Type I/II PC Cards or one Type III PC Card. (See PC Cards on page 44 for more information.)

IEEE 1394 (4-pin) Port

The 1394 port is used to connect between your LifeBook notebook and a peripheral such as a digital video camera. (See IEEE 1394 Port on page 47 for more information.)

DC Power Jack

The DC power jack allows you to plug in the AC adapter or the optional Auto/Airline adapter to power your LifeBook notebook and charge the internal Lithium ion battery.




Figure 2-5 LifeBook notebook right-side panel

RIGHT-SIDE PANEL COMPONENTS

The following is a brief description of your LifeBook notebook's right-side components. (*Figure 2-5*)

Optical Digital Audio-Out/Headphone Jack

When used as an optical digital audio-out, this jack allows you to download digital audio onto a MiniDisc recorder's SPDIF (Sony Philips Digital Interface) format. (See Optical Digital Audio-Out Connector on page 48 for more information.). When used as a headphone jack, this jack allows you to connect headphones or powered external speakers. (See Headphone Jack on page 48 for more information.)

Microphone/Line-In Jack

The microphone/Line-in jack allows you to connect an external mono microphone or device. (*See Microphone Jack on page 47 for more information.*)

Media Player Eject Button

The media player Eject Button allows you to open the media player tray to remove or install a DVD, CD-R, or CD-ROM. (See Media Player Drive on page 38 for more information.)

Media Player

The media player allows you to play back a media disc. (See Media Player Drive on page 38 for more information.)



POINT

- The media player that your LifeBook notebook uses is determined by the configuration of your system.
- The terms "media" and "media disc" in this document refer to any of the possible media drives or media discs available for your notebook (i.e., DVD, DVD-RW, CD-ROM, CD-R, or CD-RW).

Emergency Media Player Tray Release

The Emergency Media Player Tray Release allows you to open the media player tray without powering on your LifeBook notebook.

Infrared Port

The fast IrDA-compatible port allows you to communicate with another IrDA-compatible infrared device without a cable.

USB 2.0 Port

The USB port allows you to connect Universal Serial Bus 2.0 or USB 1.1 devices. Note that there are three additional USB 2.0 ports on the rear of the system. (See Universal Serial Bus Port on page 47 for more information.)

Internal Floppy Disk Drive

A standard floppy disk drive to accommodate 3.5" floppy disks. ((See Internal Floppy Disk Drive on page 37 for more information.)

Wireless LAN Switch

The Wireless LAN Switch turns the optional wireless LAN on and off. The wireless LAN option is available only on models with 15" displays. (See Integrated Wireless LAN* User's Guide on page 93 for more information.)




Figure 2-6 LifeBook notebook back panel

BACK PANEL COMPONENTS

The following is a brief description of your LifeBook notebook's back panel components. (*Figure 2-6*)

USB Ports

The four USB 2.0 ports (three on the rear, one on the right side) allow you to connect Universal Serial Bus devices. (See Universal Serial Bus Port on page 47 for more information.)

LAN Jack (RJ-45)

The LAN jack is designed to accept a Local Area Network (LAN) RJ-45 plug. (See Internal LAN (RJ-45) Jack on page 47 for more information.)

Serial Port

The serial port allows you to connect serial RS-232 devices, such as serial printers or serial scanners.

Parallel Port

The parallel port allows you to connect parallel devices, such as a printer. (This is also sometimes referred to as an LPT port.) (See Parallel Port on page 47 for more information.)

External Monitor Port

The external monitor port allows you to connect an external monitor. (See External Monitor Port on page 48 for more information.)




Figure 2-7 LifeBook notebook bottom panel

BOTTOM COMPONENTS

The following is a brief description of your LifeBook notebook's bottom panel components. (*Figure 2-7*)

Main Unit and Configuration Label

The configuration label shows the model number and other information about your LifeBook notebook. In addition, the configuration portion of the label has the serial number and manufacturer information that you will need to give your support representative. It identifies the exact version of various components of your LifeBook notebook. (See Configuration Label on page 91 for more information.)

Lithium ion Battery Bay

The battery bay contains the internal Lithium ion battery. It can be opened for the removal of the battery when stored over a long period of time or for swapping a discharged battery with a charged Lithium ion battery. (See Lithium ion Battery on page 35 for more information.)




Figure 2-8 Status Indicator Panel

Status Indicator Panel

The Status Indicator displays symbols that correspond with a specific component of your LifeBook notebook. These symbols (when visible) tell you how each of those components is operating. (*Figure 2-8*)



POWER INDICATOR

The Power indicator symbol states whether your system is operational. It has several different states, each of which tells you what mode your LifeBook notebook is in at that time.

- Steady On: This means that there is power to your LifeBook notebook and that it is ready for use.
- Flashing: This means that your LifeBook notebook is in Suspend mode.
- Steady Off (not visible): This means that your system is either in Save-to-Disk mode, or that your LifeBook notebook has been turned off with the power switch.

If you are charging your battery, the Power indicator symbol will remain on even if your LifeBook notebook is shut off. The Power indicator symbol will also remain on if you have either adapter connected and are shut down from Windows, but have not turned off the power switch.

--- AC ADAPTER INDICATOR

The AC Adapter indicator states whether your LifeBook notebook is operating from the AC adapter, the Auto/Airline adapter or the batteries. This icon has two different states that can tell you what power source your LifeBook notebook is using.

- On: This means that either of the adapters are currently in use.
- Off: Power is only coming from the batteries, and you do not have an adapter connected.

BATTERY LEVEL INDICATOR

The Battery Level indicator states whether or not the primary Lithium ion battery is installed. In addition, this symbol states how much charge is available within the battery. The symbol will only be displayed for a battery that is currently installed in your LifeBook notebook. (*Figure 2-9*)




Figure 2-9 Battery Level Indicator

CAUTION

A shorted battery is damaged and must be replaced. (Figure 2-9)



POINT

If there is no battery activity, the power adapters are not connected, or the power switch is Off, the Battery Level indicator will also be off.

→ BATTERY CHARGING INDICATOR

Located to the left of the Battery Level indicator is a small arrow symbol. This symbol indicates whether the battery is charging or not. This indicator operates whether the power switch is in the On or Off position, and will flash if the battery is too hot or cold to charge.



M CAUTION

Batteries subjected to shocks, vibration or extreme temperatures can be permanently damaged.



MEDIA PLAYER ACCESS INDICATOR

The media player Access indicator tells you that the media player drive is being accessed. If the Auto Insert Notification function is active, the indicator will flash periodically when your system is checking the media player drive. If the Auto Insert Notification function is not active, the indicator will only flash when you access the media player drive. The default setting is the Auto Insert Notification function active.

(See Auto Insert Notification Function on page 41 for more information)



HARD DRIVE ACCESS INDICATOR

The Hard Drive Access indicator states whether your internal hard drive is being accessed.



FLOPPY DRIVE ACCESS INDICATOR

The Floppy Drive Access indicator states whether the internal floppy disk drive is being accessed. This indicator will flash if your software tries to access a disk even if no floppy disk drive is installed. (See Internal Floppy *Disk Drive on page 37 for more information)*



PC CARD ACCESS INDICATORS

The PC Card Access indicators state whether or not your LifeBook notebook is accessing a PC Card. The indicators will flash if your software tries to access a PC Card even if there is no card installed. The first indicator represents the built-in PC card slot; the second indicates when a modular PC Card slot is installed. (See PC Cards on page 44 for more information)

1 NUMLK INDICATOR

The NumLk indicator states that the internal keyboard is set in ten-key numeric keypad mode.



POINT

If you are using the optional external numerical keypad, pressing the [NumLk] key will activate the external keypad. The indicator will come on, however it will not change any of the functionality of your keyboard keys.



CAPSLOCK INDICATOR

The CapsLock indicator states that your keyboard is set to type in all capital letters.



SCRLK INDICATOR

The ScrLk indicator states that your scroll lock is active.




Figure 2-10 Keyboard

Keyboard

USING THE KEYBOARD

Your LifeBook notebook has an integral 87-key keyboard. The keys perform all the standard functions of a 101-key keyboard, including the Windows keys and other special function keys. This section describes the following keys.

- Numeric keypad
- Cursor keys
- Function keys
- Windows keys

NUMERIC KEYPAD

Certain keys on the keyboard perform dual functions as both standard character keys and numeric keypad keys. NumLk can be activated by pressing the [NumLk] keys. Turning off the NumLk feature is done the same way. Once this feature is activated you can enter numerals 0 through 9, perform addition (+), subtraction (-), multiplication (*), or division (/), and enter decimal points (.) using the keys designated as ten-key function keys. The keys in the numeric keypad are marked on the front edge of the key to indicate their secondary functions.



POINT

If you are using the optional external numerical keypad, pressing the [NumLk] key will activate the external keypad. The indicator will come on, however it will not change any of the functionality of your keyboard keys.

WINDOWS KEYS

Your LifeBook notebook has three Windows keys, consisting of two Start keys and an Application key. The two Start keys display the Start menu. This button functions the same as your on-screen Start menu button. The Application key functions the same as your right mouse button and displays shortcut menus for the selected item. (Please refer to your Windows documentation for additional information regarding the Windows keys.)

CURSOR KEYS

The cursor keys are the four arrow keys on the keyboard which allow you to move the cursor up, down, left and right in applications. In programs such as Windows Explorer, it moves the "focus" (selects the next item up, down, left, or right).

FUNCTION KEYS

Your LifeBook notebook has 12 function keys, F1 through F12. The functions assigned to these keys differ for each application. You should refer to your software documentation to find out how these keys are used.

The [Fn] key provides extended functions for the LifeBook notebook and is always used in conjunction with another key.

- [Fn+F3]: Pressing [F3] while holding [Fn] will toggle the Audio Mute on and off.
- [Fn+F4]: Pressing [F4] while holding down [Fn] allows you to toggle between an internal mouse (touchpad) and an external mouse (PS/2-type).
- [Fn+F5]: Pressing [F5] while holding [Fn] allows you to toggle between video compensation and no compensation. (Video compensation controls spacing on the display. When it is enabled, displays with less than 1024 x 768 or 800 x 600 pixel resolution will still cover the entire screen.)
- [Fn+F6]: Pressing [F6] repeatedly while holding [Fn] will lower the brightness of your display.
- [Fn+F7]: Pressing [F7] repeatedly while holding [Fn] will increase the brightness of the display.
- [Fn+F10]: Pressing [F10] while holding [Fn] allows you to change your selection of where to send your display video. Each time you press the combination of keys you will step to the next choice. The choices, in order, are: built-in display panel only, both built-in display panel and external monitor or external monitor only.

Volume Control

Your LifeBook notebook has multiple volume controls which interact with each other.



Any software that contains audio files will also contain a volume control of its own. If you install an external audio device that has an independent volume control, the hardware volume control and the software volume control will interact with each other. It should be noted that if you set your software volume to Off, you will override the external volume control setting.

CONTROLLING THE VOLUME

The volume can be controlled in several different ways:

- Volume can be set from within the Volume Control on the Taskbar.
- Volume can be controlled with the [F8] and [F9] functions keys. Pressing [F8] repeatedly while holding [Fn] will decrease the volume of your notebook.
 Pressing [F9] repeatedly while holding [Fn] will increase the volume of your notebook.
- Volume can be controlled by many volume controls that are set within individual applications.
- Certain external audio devices you might connect to your system may have hardware volume controls.

Each source discussed above puts an upper limit on the volume level that must then be followed by the other sources.

We recommend that you experiment with the various volume controls to discover the optimal sound level.




Figure 2-11 Touchpad pointing device

Touchpad Pointing Device

The Touchpad pointing device comes built into your LifeBook notebook. It is used to control the movement of the pointer to select items on your display panel. The Touchpad is composed of a cursor control, a left and right button, and a scrolling button. The cursor control works the same way a mouse does, and moves the cursor around the display. It only requires light pressure with the tip of your finger. The left and right buttons function the same as mouse buttons. The actual functionality of the buttons may vary depending on the application that is being used. The scrolling button allows you to navigate quickly through pages, without having to use the scroll bars. (Figure 2-11)

CLICKING

Clicking means pushing and releasing a button. To left-click, move the cursor to the item you wish to select, press the left button once, and then immediately release it. To right-click, move the mouse cursor to the item you wish to select, press the right button once, and then immediately release it. You also have the option to perform the clicking operation by tapping lightly on the Touchpad once. (*Figure 2-12*)



Figure 2-12 Clicking

DOUBLE-CLICKING

Double-clicking means pushing and releasing the left button twice in rapid succession. This procedure does not function with the right button. To double-click, move the cursor to the item you wish to select, press the left button twice, and then immediately release it. You also have the option to perform the double-click operation by tapping lightly on the Touchpad twice. (*Figure 2-13*)



Figure 2-13 Double-clicking

POINT

- If the interval between clicks is too long, the double-click will not be executed.
- Parameters for the Touchpad can be adjusted from the Mouse Properties dialog box located in the Windows Control Panel.

DRAGGING

Dragging means pressing and holding the left button, while moving the cursor. To drag, move the cursor to the item you wish to move. Press and hold the left button while moving the item to its new location and then release it. Dragging can also be done using the Touchpad. First, tap the Touchpad twice over the item you wish to move making sure to leave your finger on the pad after the final tap. Next, move the object to its new location by moving your finger across the Touchpad, and then release your finger. (Figure 2-14)




Figure 2-14 Dragging

SCROLLING

Using the Scrolling button allows you to navigate through a document quickly without using the window's scroll bars. This is particularly useful when you are navigating through on-line pages. To use the Scrolling button, press the crescent shape at the top or bottom of the button to scroll up or down a page. When you have reached the desired section of the page, release the button. (*Figure 2-15*)



Figure 2-15 Scrolling

TOUCHPAD CONTROL ADJUSTMENT

If you need to change or adjust any of the touchpad control functions, you can customize them from the Mouse properties dialog box in the Control Panel. Click on Start, select Settings > Control Panel, then double-click Mouse.




Figure 2-16 LifeBook Application Launcher Buttons

LifeBook Application Panel

A unique feature of your LifeBook notebook is the Life-Book Application Panel. This panel allows you to operate the media player drive either as an independent audio media player or to launch applications with the touch of one button.



POINT

- LifeBook Application Panel uses the date and time settings of your LifeBook notebook. If the date and time are incorrect, you can adjust this setting in the Windows Control Panel.
- The media player that your LifeBook notebook uses is determined by the configuration of your system.

Your LifeBook notebook is pre-installed with software utilities that let you operate and configure your LifeBook Application Panel. These utilities are found under the Start menu, under Programs, then under LifeBook Application Panel. They include a media player, Application Panel Setup, Application Panel Guide, Activate Panel and Deactivate Panel. The LifeBook Application Panel system makes your LifeBook notebook more than just another notebook computer.

The panel consists of the following elements:

SELECTOR SWITCH

Located at the far left of the panel, this switch allows you to select the function of the panel—either as an Application Launcher, a media player, or as a lock.

The buttons can be locked and unlocked by pressing either of the selector switch positions for four seconds or longer. When the selector switch is in Lock mode, the buttons are disabled and do nothing when pressed.

APPLICATION LAUNCH MEDIA PLAYER BUTTONS

When the selector switch is in the Application position, pressing any of the buttons will launch a user-defined application. When the selector switch is in the Media Player position, the buttons operate the media player.

CONFIGURING YOUR LIFEBOOK APPLICATION PANEL

When you start your system, the LifeBook Application Panel is automatically activated. An icon resembling a finger pressing a button will appear on the system tray (the indented portion of the status bar where the clock is displayed). When you see this icon you will know that the LifeBook Application Panel is active.

As an application launcher, the LifeBook Application Panel is very flexible, giving you a variety of options. To set up the Panel to best suit your needs, we have provided the Application Panel Setup utility that quickly and easily helps you make the most of this valuable feature.

To configure your LifeBook Application Panel with Application Panel Setup:

- 1. Click on Start.
- 2. Click on **Programs**.
- 3. Click on LifeBook Application Panel.
- 4. Click on Application Panel Setup.

The Application Panel Setup utility will appear. There are tabs that correspond to the application buttons on the LifeBook Application Panel. When you receive your LifeBook notebook, these buttons are pre-configured to launch specific programs. (See Specifications on page 91 for more information).



POINT

The tabs in Application Panel Setup may not be in the same order as the buttons on your LifeBook notebook. Please select the tab you wish to change carefully.

To change an application associated with one of the buttons, click on the tab for the button you would like to reconfigure. Click on Browse from the Start Menu, scroll down the list of applications, click on the application you wish to launch with this button, and then click OK. The button will now launch the new application.

One of the buttons may be preconfigured to launch your default Internet browser. In order to reconfigure it to launch a different program, follow these easy steps:

- 1. Click on Other from the Internet browser box.
- 2. Click on Browse from Start Menu.
- 3. Scroll down the list of applications, and click on the application you wish to launch with this button.
- 4. Click OK.

The button will now launch the new application. If you want to return to launching your default Internet browser with this button, you need only click on "Default Internet Browser" from the Internet browser box. Be aware that you will erase the settings for the "other application". If you wish to go back to launching the "other application" from this button, you will need to reconfigure it as described above.

At the bottom of each application setup page are two selectable options. The first will enable/disable the button when your LifeBook notebook is in Standby mode, and the second will enable/disable the button when your LifeBook notebook is in the pseudo-off state. You can enable/disable either or both of these functions simply by clicking on the option.



POINT

If you choose to have the buttons work when the Life-Book notebook is in standby, they will function even if hit accidentally, and will turn on your LifeBook notebook even if you are not present or using your LifeBook notebook. This could deplete your battery, and you will need to recharge it before using the LifeBook notebook. As a precaution, press the selector switch for four or more seconds to lock the buttons when you are away from your LifeBook notebook. To unlock the buttons, repeat the procedure.

When you have finished with Application Panel Setup, click on OK, and the new settings will take effect. You

can reconfigure your LifeBook Application Panel as often as you like.

USING THE MEDIA PLAYER

The media player enables you to use your LifeBook notebook's media player drive as an audio media player.



POINT

- If you shut down from Windows while the media player is playing an audio CD, it will stop.
- You cannot go into Suspend Mode or Hibernation (Save-to-Disk) Mode while the media player is playing a CD.
- The media player will only play when the system is powered on.

There is no configuration required for media player operation. The buttons are pre-configured to work like a normal media player. When the selector switch is in the bottom position, the buttons will operate as follows:

- Stop/Eject: This is the first button to the right of the Selector switch. If you press it once, it will stop an audio CD that is playing. If you press it twice, it will eject the audio CD.
- Play/Pause: This is the second button to the right of the Selector switch. Press this button to start playing an audio CD starting at Track 1. While the audio CD is playing, press it to pause. Press it again to continue.



POINT

- If you press the play button and nothing happens, you either have the Selector switch locked, there is no audio CD in the media player drive, you have a CD other than an audio CD in the drive, or system is not powered on.
- Because of the Windows CD auto-insertion function, audio CDs will start playing immediately after they are inserted if your LifeBook notebook is On. This will not happen if you are using the media player in Suspend or Pseudo-off modes.
- Fast Backward: This is the third button to the right of the Selector switch. Press this button once to skip one track back.
- Fast Forward: This is the fourth button to the right of the Selector switch. Press this button once to skip forward one track.

DESKTOP CONTROL PANEL

Your LifeBook notebook includes a desktop control panel for your notebook's desktop that you can use at any time. You may use this panel to operate the media

player when you have the Selector switch in the Application position or Lock mode.

To use the desktop control panel:

- 1. Click on Start.
- 2. Click on Programs.
- 3. Click on Lifebook Application Panel.
- 4. Click on Display CD Player.

The desktop control panel will appear in the upper right corner of your screen. To close the panel:

1. Click on the "x" button.

To minimize the panel:

2. Click on the "-" button.

You can select from four appearances for your desktop control panel. Simply double click on the track display area of the panel, and a menu will appear which will allow you to select from a pull down menu. On the same pop-up are two other options: "Always on top" and "Continuous Play". If you click on "Always on top" the desktop controls will always be seen on your screen, no matter what other application you are running. If you click on "Continuous Play", your media player will automatically start over at the beginning of the CD in the drive as soon as it finishes the last track.

You can move the desktop control panel to anywhere on your desktop. Drag it by clicking on the track number display, holding it down, and dragging the control panel. When you place it where you would like, release the mouse button.

POINT

- If you have your display set to 256 colors, the basic display will appear no matter which one you select.
 You will need to set your display colors to more than 256 in order to select other display appearances.
- When you close the media player's desktop control panel, it will stop the audio media player. Simply press the Play button if you would like to continue listening, and the media player will restart at track 1. The Selector switch must be in the media player position.

Deactivating and Activating the LifeBook Application Panel

To deactivate the LifeBook Application Panel, follow these easy steps:

- 1. Click on Start.
- 2. Click on Programs.
- 3. Click on LifeBook Application Panel.
- 4. Click on Deactivate Panel.

To reactivate, follow the same procedure, except for step 4. Click on Activate Panel instead.



POINT

Every time you start Windows, the LifeBook Application Panel is activated, even if you deactivated it before you shut down.

Application Panel Setup

- If you insert an audio CD which has both audio and data tracks into the media player drive, the media player may fail to play the first audio track.
- The Volume Up, Volume Down and Mute controls for the media player desktop control panel adjusts the volume of the CD audio line only. It does not adjust your LifeBook notebook's master software volume control.
- The media player desktop control panel is designed to be displayed in High Color (16-bit) or in True Color (24-bit or more). If you have your LifeBook notebook's display set for 256 colors or less Media Player will display in a "basic" mode.

Getting Started

LifeBook C Series Notebook - Section Three




Figure 3-1 Connecting the AC Adapter

Power Sources

Your LifeBook notebook has three possible power sources: a primary Lithium ion battery, an AC adapter or an optional Auto/Airline adapter.

CONNECTING THE POWER ADAPTERS

The AC adapter or optional Auto/Airline adapter provides power for operating your LifeBook notebook and charging the batteries.

Connecting the AC Adapter

- Plug the DC output cable into the DC power jack of your LifeBook notebook.
- 2. Plug the AC adapter into an AC electrical outlet.

Connecting the Optional Auto/Airline Adapter

- 1. Plug the DC output cable into the DC power jack on your LifeBook notebook.
- Plug the Auto/Airline adapter into the cigarette lighter of an automobile with the ignition key in the On or Accessories position.
- 3. Plug the Auto/Airline adapter into the DC power jack on an airplane seat.

Switching from AC Adapter Power or the Auto/Airline Adapter to Battery Power

- 1. Be sure that you have at least one charged battery installed.
- 2. Remove the AC adapter or the Auto/Airline adapter. Your notebook will automatically switch from DC power to battery power.



The Lithium ion battery is not charged upon purchase. Initially, you will need to connect either the AC adapter or the Auto/Airline adapter to use your LifeBook notebook.




Figure 3-2 Opening the Display Panel (15" model shown)

Display Panel

Your LifeBook notebook contains a display panel that is backlit for easier viewing in bright environments and maintains top resolution through the use of active-matrix technology. Your system has either a 14.1" or a 15" display panel. The 15" model is illustrated throughout this document.

OPENING THE DISPLAY PANEL

- Slide the latch located at the top of the display panel to the right. This releases the locking mechanism and raises the display slightly.
- 2. Lift the display backwards, being careful not to touch the screen, until it is at a comfortable viewing angle.

ADJUSTING DISPLAY PANEL BRIGHTNESS

Once you have turned on your LifeBook notebook, you may want to adjust the brightness level of the screen to a more comfortable viewing level. There are two ways to adjust the brightness, keyboard and power management utility.



POINT

The higher the brightness level, the more power the LifeBook notebook will consume and the faster your batteries will discharge. For maximum battery life, set the brightness to as low a level as possible.

Keyboard

Adjusting the brightness using the keyboard changes the setting only temporarily.

- [Fn+F6]: Pressing repeatedly will lower the brightness of your display.
- [Fn+F7]: Pressing repeatedly will increase the brightness of the display.

Using the Power Management Utility (Windows 2000 only)

Adjusting the brightness using the Power Management changes the setting permanently.

- Double-click the BatteryAid icon in the lower right corner of your display. This will open the BatteryAid Properties dialog box.
- 2. Select the Power Control tab and adjust your LCD Backlighting to the desired level.
- 3. Click **OK** or **Apply** to permanently change the settings.

You may need to readjust the brightness level periodically depending on your operating environment.



POINT

The higher the brightness level, the more power the notebook will consume and the faster your batteries will discharge. For maximum battery life, make sure that the brightness is set as low as possible.

CLOSING THE DISPLAY PANEL

- Holding the edge of your display panel, pull it forward until it is flush with the body of your LifeBook notebook.
- Push down until you hear a click. This will engage the locking mechanism and prevent your display panel from opening unexpectedly.

Starting Your LifeBook Notebook

POWER ON

Suspend/Resume/Power On Button

The suspend/resume/power on switch is used to turn on your LifeBook notebook from its off state. Once you have connected your AC adapter or charged the internal Lithium ion battery, you can power on your LifeBook notebook. (See figure 2-3 on page 8 for location)



When you turn on your LifeBook notebook be sure you have a power source. This means that at least one battery is installed and charged, or that the AC or Auto/ Airline adapter is connected and has power.

To turn on your LifeBook notebook from its off state, press the suspend/resume/on button, located above the keyboard. When you are done working you can either leave your LifeBook notebook in Suspend mode, (See Suspend Mode on page 30 for more information), or you can turn it off. (See Power Off on page 31 for more information)

CAUTION

Do not carry your LifeBook notebook around with the power on or subject it to shocks or vibration, as you risk damaging your notebook.

When you power on your LifeBook notebook, it will perform a Power On Self Test (POST) to check the internal parts and configuration for correct functionality. If a fault is found, your LifeBook notebook will emit an audio warning and/or an error message will be displayed. (See Power On Self Test Messages on page 80 for more information) Depending on the nature of the problem, you may be able to continue by starting the operating system or by entering the BIOS setup utility and revising the settings.

After satisfactory completion of the Power On Self Test (POST), your LifeBook notebook will load your operating system.

POINT

Never turn off your LifeBook notebook during the Power On Self Test (POST) or it will cause an error message to be displayed when you turn your LifeBook notebook on the next time. (See Power On Self Test Messages on page 80 for more information)

BOOT SEQUENCE

The procedure for starting-up your LifeBook notebook is termed the Bootup sequence and involves your LifeBook notebook's BIOS. When your LifeBook notebook is first turned on, the main system memory is empty, and it needs to find instructions to start up your LifeBook notebook. This information is in the BIOS program. Each time you power up or restart your LifeBook notebook, it goes through a boot sequence which displays a Fujitsu logo until your operating system is loaded. During booting, your LifeBook notebook is performing a standard boot sequence including a Power On Self Test (POST). When the boot sequence is completed without a failure and without a request for the BIOS Setup Utility, the system displays the operating system's opening screen.

The boot sequence is executed when:

- You turn on the power to your LifeBook notebook.
- You restart your LifeBook notebook from the Windows Shut Down dialog box.
- The software initiates a system restart.
 Example: When you install a new application.
- You reset the system by pressing the three keys [CTRL+ALT+DEL].

BIOS SETUP UTILITY

The BIOS Setup Utility is a program that sets up the operating environment for your LifeBook notebook. Your BIOS is set at the factory for normal operating conditions, therefore there is no need to set or change the BIOS' environment to operate your LifeBook notebook.

The BIOS Setup Utility configures:

- Device control feature parameters, such as changing I/O addresses and boot devices.
- System Data Security feature parameters, such as passwords.

Entering the BIOS Setup Utility

To enter the BIOS Setup Utility do the following:

- 1. Turn on or restart your LifeBook notebook.
- 2. Press the [F2] key once the Fujitsu logo appears on the screen. This will open the main menu of the BIOS Setup Utility with the current settings displayed.
- Press the [RIGHT ARROW] or [LEFT ARROW] key to scroll through the other setup menus to review or alter the current settings.

BIOS Guide

A guide to your LifeBook notebook's BIOS is available online. Please visit our service and support web site at www.fujitsupc.com. Once there, click on the Support link, then select Notebooks under User's Guides in the side bar. Select LifeBook BIOS Guides from the pulldown menu for your LifeBook model.



POINT

If your data security settings require it, you may be asked for a password before the BIOS main menu will appear.

BOOTING THE SYSTEM

We strongly recommend that you not attach any external devices and do not put a DVD/CD in your drive until you have gone through the initial power on sequence.

When you turn on your LifeBook notebook for the first time, it will display a Fujitsu logo on the screen. If you do nothing the system will load the operating system, and then the Windows Welcome will begin.

Designed to accommodate the needs of many users, in many different countries, Windows needs to be configured the first time you use them. Windows has two parts:

- Getting Started: You have the opportunity to review the Windows License Agreement, to enter custom information for your system, and to set up your modem so that your LifeBook notebook will be prepared to dial out.
- Registration: Easy online registration for Windows with Microsoft.



POINT

You may click Cancel at any time within this process to shut down Windows. You may restart this process at any time in the future, but you must complete it in order to use your computer.

Getting Started

Read the instructions on the screens carefully and fill in the information as directed. You will be asked to read the Windows End User License Agreement. When you finish reading you must accept or reject the terms of the agreement.



POINT

If you reject the terms of the License Agreement you will be returned to the beginning of the Windows Welcome Process, even if you shut your notebook down and start it up again.

You will then be asked for such items as the language you wish to use, the country in which you live, your first and last name, and about how you dial out from where you will be using your LifeBook notebook. For the modem settings, enter your current location information where you will be using your LifeBook notebook. If you are not connected to a phone line and plan to register at a later time, you may click the **Skip** button.

Once you have set up your LifeBook notebook to dial out, Windows will make a free telephone call to test the settings. If the call is unsuccessful, you will be returned to the phone settings page where you may try to fix them. If you are unable to fix the settings please contact Fujitsu Service and Support. (See Fujitsu Contact Information on page 3 for more information) If you would simply like to move on, and register at a later time, you may click the Skip button.

Windows Registration

If your connection is successful, you will receive an acknowledgement from Microsoft that your registration was successful.

WINDOWS PRODUCT ACTIVATION (WINDOWS XP ONLY)

If your system has Windows XP as an operating system, it has *already* been pre-installed and pre-activated when you receive the system.

In the event you need to re-install Windows XP (e.g., after making significant configuration changes), it may be necessary to reactivate the operating system. To do so, use the following information.

- After re-installing Windows XP, you have thirty days to activate it. Product activation ensures that you are the authorized owner of the Windows XP operating system.
- Until you activate the product, you will be prompted whenever you turn on the system that activation is

required. Follow the on-screen directions to activate your operating system. The product only needs to be activated once, unless significant hardware changes are made to your system.

 Note that Product Activation and Registration are not the same thing. Registration is optional, whereas Product Activation is a required procedure.

REGISTERING YOUR LIFEBOOK NOTEBOOK What are the benefits of registering?

You will receive an identification label for your LifeBook notebook, which, if your notebook is ever lost, may help in getting it returned to you. You will also receive technical support access and useful product mailings.

How do I register my LifeBook notebook?

There are four ways to register your LifeBook notebook.

Complete the pre-printed registration form and submit it by either of the following methods:

■ Fax: 1-800-577-9989

 Mail: Fujitsu PC Corporation 750 139th Ave.
 San Leandro, CA 94578 Attn: Warranty Department

You can also register your LifeBook by:

■ Web site: www.fujitsupc.com/support

You will need to be set up with an Internet Service Provider (ISP) to use the last option.

INSTALLING CLICK ME!

The first time you boot up your system, you will see an icon called Click Me! on the desktop (Windows 2000) or in the Start folder (Windows XP). When you click the Click Me! icon, your system will automatically build the icon tray in the bottom right of the screen. These icons provide links to utilities that you will frequently access.

Power Management

Your LifeBook notebook has many options and features for conserving battery power. Some of these features are automatic and need no user intervention, such as those for the internal modem. However, others depend on the parameters you set to best suit your operating conditions, such as those for the display brightness. Internal power management for your LifeBook notebook may be controlled from settings made in your operating system, pre-bundled power management application, or from settings made in BIOS setup utility.

Besides the options available for conserving battery power, there are also some things that you can do to prevent your battery from running down as quickly. For example, you can create an appropriate power saving profile, put your LifeBook notebook into Suspend mode when it is not performing an operation, and you can limit the use of high power devices. As with all mobile, battery powered computers, there is a trade-off between performance and power savings.

SUSPEND/RESUME/POWER ON BUTTON

When your LifeBook notebook is active, the Suspend/ Resume/Power On button can be used to manually put your LifeBook notebook into Suspend mode. Push the Suspend/Resume/Power On button when your LifeBook notebook is active, but not actively accessing anything, and immediately release the button. You will hear two short beeps and your system will enter Suspend mode.

If your LifeBook notebook is suspended, pushing the Suspend/Resume/Power On button will return your LifeBook notebook to active operation. You can tell whether or not your system is in Suspend mode by looking at the Power icon on the Status LCD Panel. (See Status Indicator Panel on page 13 for more information) If the indicator is visible and not flashing, your LifeBook notebook is fully operational. If the indicator is both visible and flashing, your LifeBook notebook is in Suspend mode. If the indicator is not visible at all, the power is off or your LifeBook notebook is in Hibernation (Save-to-Disk) mode. (See Hibernation Feature)

SUSPEND MODE

Suspend or Standby mode saves the contents of your LifeBook notebook's system memory during periods of inactivity by maintaining power to critical parts. This mode will turn off the CPU, the display, the hard drive, and all of the other internal components except those necessary to maintain system memory and allow for restarting. Your LifeBook notebook can be put in Suspend mode by:

- Pressing the Suspend/Resume / Power On button when your system is turned on.
- Selecting Standby from the Windows Shut Down menu.
- Timing out from lack of activity (if the power profile has been set up accordingly).
- Allowing the battery to reach the Dead Battery Warning condition.

Your LifeBook notebook's system memory typically stores the files on which you are working, opens applications information, and any other data required to support the operations in progress. When you resume operation from Suspend mode, your LifeBook notebook will return to the point where it left off. You must use the Suspend/Resume/Power On button to resume operation, and there must be an adequate power source available, or vour LifeBook notebook will not resume.



POINT

If you are running your LifeBook notebook on battery power, be aware that the battery continues to discharge while your LifeBook notebook is in Suspend mode, though not as fast as when fully operational.

HIBERNATION (SAVE-TO-DISK) FEATURE

The Hibernation (Save-to-Disk) feature saves the contents of your LifeBook notebook's system memory to the hard drive as a part of the Suspend/Resume mode. You can enable or disable this feature

Enable or Disable the Hibernation Feature

Hibernation is the default setting for Windows XP. To disable or enable the Hibernation feature, follow these steps:

- 1. From the **Start** menu, select **Settings**, and then select Control Panel.
- 2. From the Control Panel, select Power Options.
- 3. Select the **Hibernation** tab. Select or deselect the box to enable or disable this feature.

Using the Hibernation Feature

- 1. From the **Start** menu, select **Settings**, then select Control Panel.
- 2. From the Control Panel, select Power Options.
- 3. Select the Advanced tab. Select Hibernate from the pull down menu for Power buttons.



∤X CAUTION

The Suspend or Hibernation (Save-to-Disk) mode should not be used with certain PC Cards. Check your PC Card documentation for more information.



POINT

- If your LifeBook notebook is actively accessing information when you enter the Suspend or Hibernation (Save-to-Disk) mode, changes to open files are not lost. The files are left open and memory is kept active during Suspend mode or the memory is transferred to the internal hard drive during Hibernation (Save-to-Disk) mode.
- When PC Cards or external devices are in use. Save-to-Disk mode cannot return to the exact state prior to suspension, because all of the peripheral devices will be re-initialized when the system
- The main advantage of using the Hibernation (Save-to-Disk) function is that power is not required to maintain your data. This is particularly important if you will be leaving your LifeBook notebook in a suspended state for a prolonged period of time. The drawback of using Hibernation (Save-to-Disk) mode is that it lengthens the power down and power up sequences and resets peripheral devices.

DISPLAY TIMEOUT

The Video Timeout is one of the power management parameters. This feature saves power by turning off the display if there is no keyboard or pointer activity for the user selected timeout period. Any keyboard or pointer activity will cause the display to restart automatically. This feature is independent of the Suspend/Resume/ Power On button and can be enabled and disabled in Windows and BIOS setup utility. (See BIOS Setup Utility on page 27 for more information)

HARD DISK TIMEOUT

The Hard Disk Timeout is another one of the power management parameters. This feature saves power by turning off the hard drive if there is no hard drive activity for the user selected timeout period. Any attempt to access the hard drive will cause it to restart automatically. This feature is independent of the Suspend/Resume/Power On button and can be enabled and disabled in Windows and BIOS setup utility. (See BIOS Setup Utility on page 27 for more information)

WINDOWS POWER MANAGEMENT

The Power Management icon located in the Windows Control Panel allows you to configure some of the power management settings. For example, you can use the Power Management to set the timeout values for turning off the display and hard disks whether you are running the LifeBook notebook on battery power or one of the adapters. (See Pre-Installed Software on page 93 for more information) The settings may also be changed in the BIOS. (See BIOS Setup Utility on page 27 for more information)

RESTARTING THE SYSTEM

If your system is on and you need to restart it, be sure that you use the following procedure.

- 1. Click the Start button, and then click Shut Down.
- 2. Select the **Restart** option from within the Windows Shut Down dialog box.
- 3. Click **OK** to restart your LifeBook notebook. Your notebook will shut down and then reboot.



POINT

Turning off your LifeBook notebook without exiting Windows or turning on your notebook within 10 seconds of the notebook being shut off may cause an error when you start the next time.

POWER OFF

Before turning off the power by choosing Shut Down from Windows, check that the Hard Drive, media player drive, PC Card and Floppy Disk Drive Access indicators are all Off. (See figure 2-8 on page 13) If you turn off the power while accessing a disk or PC Card there is a risk of data loss. To ensure that your LifeBook notebook shuts down without error, use the Windows shut down procedure.



₩ CAUTION

Never turn your LifeBook notebook off while an application is running. Be sure to close all files, exit all applications, and shut down your operating system prior to turning off the power with the power switch. If files are open when you turn the power off, you will lose any changes that have not been saved, and may cause disk errors.

Using the correct procedure to shut down from Windows, allows your LifeBook notebook to complete its operations and turn off power in the proper sequence to avoid errors. The proper sequence is:

- 1. Click the Start button, and then click Shut Down.
- 2. Select the **Shut Down** option from within the Windows Shut Down dialog box.
- 3. Click **OK** to shutdown your LifeBook notebook.

If you are going to store your LifeBook notebook for a month or more see Care and Maintenance Section.

LifeBook C Series Notebook - Section Three

4 User-Installable Features

LifeBook C Series Notebook - Section Four

Lithium ion Battery

Your LifeBook notebook has a Lithium ion battery that provides power for operating your LifeBook notebook when no external power source is available. The battery is durable and long lasting, but should not be exposed to extreme temperatures, high voltages, chemicals or other hazards.

The Lithium ion battery operating time may become shorter if it is used under the following conditions:

- When used at temperatures that exceeds a low of 5°C or a high of 35°C. Extreme temperatures not only reduce charging efficiency, but can also cause battery deterioration. The Charging icon on the Status Indicator panel will flash when you try to charge a battery that is outside its operating temperature range. (See Battery Charging Indicator on page 14 for more information)
- When using a high current device such as a modem, DVD, or hard drive, using the AC adapter will conserve your battery life.

M CAUTION

- Actual battery life will vary based on screen brightness, applications, features, power management settings, battery condition and other customer preferences. Media player drive or hard drive usage may also have a significant impact on battery life. The battery charging capacity is reduced as the battery ages. If your battery is running low quickly, you should replace it with a new one.
- Do not leave a faulty battery in your LifeBook notebook. It may damage your AC adapter, optional Auto/Airline adapter, a second battery or your Life-Book notebook itself. It may also prevent operation of your LifeBook notebook by draining all available current into the bad battery.
- Under federal, state, or local law it may be illegal to dispose of batteries by putting them in the trash. Please take care of our environment and dispose of batteries properly. Check with your local government authority for details regarding recycling or disposing of old batteries. If you cannot find this information elsewhere, contact your support representative at 1-800-8Fujitsu (1-800-838-5487).

RECHARGING THE BATTERIES

If you want to know the charge condition of the primary Lithium ion battery, check the Battery Level indicator located on the Status Indicator panel. The indicator changes as the battery level changes.

The Lithium ion battery is recharged internally using the AC adapter or Auto/Airline adapter. To recharge the battery make sure the battery that needs to be charged

is installed in your LifeBook notebook and connect the AC or Auto/Airline adapter. The Lithium ion battery can also be charged using an external battery charger, available from Fujitsu.



POINT

Make sure that the Battery Charging indicator and the percentage charge is shown inside the Battery Level icon on the Status Indicator Panel.

There is no memory effect on the Lithium ion battery, therefore you do not need to discharge the battery completely before recharging. The charge times will be significantly longer if your LifeBook notebook is in use while the battery is charging. If you want to charge the battery more quickly, put your LifeBook notebook into Suspend mode, or turn it off while the adapter is charging the battery. (See Power Management on page 30 for more information on Suspend mode and shutdown procedure)

M CAUTION

Using heavy current devices such as a Modem or frequent media player accesses may prevent charging completely.

Low Battery State

When the battery is running low, a low battery notification message will appear. If you do not respond to the low battery message, the batteries will continue to discharge until they are too low to operate. When this happens, your LifeBook notebook will go into Suspend mode. There is no guarantee that your data will be saved once the notebook reaches this point.

M CAUTION

- Once the low battery notification message appears, you need to either plug in an AC power adapter or Auto/Airline adapter, or save all your active data, power down your system, and install a charged battery as soon as possible.
- When you are in Suspend mode there must always be at least one power source active. If you turn off the power with the power switch, or remove all power sources while your LifeBook notebook is in Suspend mode, any data that has not been saved to the hard drive will be lost.

Dead Battery Suspend mode shows on the Status indicator just like the normal Suspend mode. Once your LifeBook notebook goes into Dead Battery Suspend mode you will be unable to resume operation until you provide a source of power either from an adapter or a charged battery. Once you have provided power, you will need to press the Suspend/Resume button to resume operation. In the Dead Battery Suspend mode, your data will be lost if a power source is not provided promptly. If the Power indicator stops flashing and goes out, you have lost the data that was not stored. Once you provide power, you can continue to use your LifeBook notebook while an adapter is charging the battery.

Shorted Batteries

The Status Indicator panel uses a symbol inside the battery outline of the Battery Level indicator to display the operating level available in that battery. (See figure 2-9 on page 13) If this display shows a Shorted Battery, it means that the battery is damaged and must be replaced so it does not damage any other parts of your LifeBook notebook.

REPLACING THE BATTERY

With the purchase of an additional battery, you can have a fully charged spare to swap with one that is not charged. (*Figure 4-1*)

- 1. Have a charged battery ready to install.
- 2. Shut down your LifeBook notebook and disconnect the AC adapter.
- 3. Press the battery release latch while lifting the battery.

- 4. Remove the battery from the bay.
- 5. Slide the new battery into the bay. The pins will automatically align with the connector.
- 6. Press the battery down until the battery release latch snaps into place.
- 7. Plug in the AC adapter and turn the power on.




Figure 4-1 Replacing the Battery



If the Lithium ion battery connector is not fully seated, you may not be able to use your LifeBook notebook or charge your battery.




Figure 4-2 Loading/Ejecting a 3.5" Floppy Disk

Internal Floppy Disk Drive

Your LifeBook notebook has an internal floppy disk drive which can read and write information on removable 1.44MB and 720KB floppy disks.

LOADING A DISK

To load a disk into your disk drive, follow these easy steps:

- 1. Position the disk so that its label is facing upwards and the shutter side is pointing towards the drive. (*Figure 4-2*)
- 2. Push the disk into the drive until the Eject button pops out and you hear a click.



When there is no disk in the drive, the Eject button is flush with your LifeBook notebook.

EJECTING A DISK

To eject a disk from the disk drive, follow these easy steps:

- Check that the Floppy Disk Drive Access indicator is inactive.
- 2. Press the Eject button. This will push your disk partially out of the drive.
- 3. Remove the disk.

CAUTION

- If you eject the disk while the Floppy Disk Drive Access indicator is active, there is a risk of damaging the data on the disk, the disk itself or even the disk drive.
- Formatting a floppy disk that already contains data will erase all of the information on the disk.

PREPARING A DISK FOR USE

Before you can use a new disk, it needs to be prepared so your LifeBook notebook knows where to store information. This preparation is called formatting or initializing a disk. You will need to format new disks, unless they are preformatted. (Please refer to your operating system manual for step-by-step instructions on formatting a disk)

To prevent accidental erasure of the data stored on a disk, slide the "write protect" tab until a small hole is exposed. This sets the disk into a protected state where nothing can be added or removed. If you want to add or remove data on a protected disk, slide the "write protect" tab to close the small hole. (*Figure 4-3*)




Figure 4-3 Floppy Disk Write Protect




Figure 4-4 Media Player Drive

Media Player Drive

There is avariety of media available to use with your system, depending upon the system configuration you have selected.

DVD-R and DVD-RW discs hold up to 4.7GB of data. A DVD-R disc can only be written to once; DVD-RW discs can be written to over and over. DVD-R and DVD-RW discs can be played on most standard DVD players.

CD-R and CD-RW discs hold up to 640MB of data. A CD-R disc can only be written to once; CD-RW discs can be written to over and over.

Depending upon the configuration of your LifeBook notebook, you may have one of the following drives:

DVD-RW

A DVD-RW drive allows you to play CD's and DVD's, record CD-R's and CD-RW's, and record DVD-R's and DVD-RW's.

■ DVD/CD-RW combo

A DVD/CD-RW combo drive allows you to access movie, software, data, or audio DVD/CDs, and to write data onto recordable CD-R and CD-RW discs.

DVD

A DVD player gives you access to movie, software, data, and audio DVD/CDs.

CD-ROM

A CD-ROM drive allows you to access software, data, or audio CDs.



POINT

Install your media player software before first using the DVD, DVD/CD-RW, or DVD-RW media drives. Refer to the applicable readme file on the Driver Applications CD-ROM.

MEDIA PLAYER SOFTWARE

DVD model only: With the media player drive and media player software you can play DVD movies on your Life-Book notebook. The media player includes controls

which allow you to take full advantage of the features of a DVD movie, as well as standard features such as fast forward, fast reverse, pause, etc.

<u>DVD/CD-RW Combo model only:</u> With the combo drive, you can play DVD movies, read audio CDs, and write data onto recordable CD-R or CD-RW discs.

<u>DVD-RW model only:</u> With this drive, you can play CD's and DVD's, record CD-R's and CD-RW's, and record DVD-R's and DVD-RW's



₩ CAUTION

- Do not operate your media player drive unless your LifeBook notebook is sitting on a flat surface. Using a drive when the system is not level may damage the drive or prevent proper operation.
- Prolonged use of the media player drive, such as watching a DVD movie, will substantially reduce your battery life if no other power source is attached.



POINT

- You should periodically check the Fujitsu web site at www.fujitsupc.com for current updated drivers.
- All LifeBook DVD players are set to play DVD titles with region code number 1 which is specified for the North American market. The region number is a regional restriction code defined by the DVD Forum acting on Hollywood requirements. Different region codes are recorded on video DVD titles for publication in different areas of the world. If the regional code of the DVD player does not match the regional codes on the titles, then playback is impossible.
- You can change the region code on the DVD player using the Properties menu of the DVD software. Note, however, that you can only change the region code up to four times. After the fourth change, the last region code entered becomes permanent, and cannot be changed.

LOADING MEDIA ON YOUR DRIVE

To load a disc into your media player drive:

- Push and release the eject button on the front of the media player drive to open the holder tray. The tray will come out of the LifeBook notebook a short distance.
- 2. Gently pull the tray out until a media disc can easily be placed in the tray.



CAUTION

There may be a protective sheet in the tray from when it was shipped; please make sure it is removed before operating the drive.

- Place the media into the tray, label side up, with the hole in the center of the disc. Snap the disc onto the raised circle in the center of the tray.
- 4. Gently push the holder tray back in until you hear a click. (*Figure 4-5*)



POINT

If you have disabled the Auto Insert Notification Function, you will have to start the drive from your desktop, since your LifeBook notebook will not automatically recognize that media has been loaded.




Figure 4-5 Loading/Ejecting Media

REMOVING MEDIA

 Push and release the eject button on the front of the media player drive. This will stop the drive and the holder tray will come out of the LifeBook notebook a short distance.

- 2. Gently pull the tray out until the disc can easily be removed from the tray.
- Carefully remove the media disc from the holder tray.
- Gently push the holder tray back in until you hear a click.

USING THE MEDIA PLAYER SOFTWARE



POINT

Depending upon its configuration, your system may not have the media player software pre-installed. If it is not installed, reference the documentation that accompanies the media application.

Starting a DVD Movie (DVD Models only)

- Insert the DVD movie into the media player drive of your notebook. If the CD AutoRun feature activates, skip Step 2.
- 2a. Windows 2000 only: From the Start menu, select Programs, then select InterVideo WINDVD and click InterVideo WINDVD or double-click on the InterVideo WINDVD icon on the desktop. This will launch the DVD movie.
- 2b. Windows XP only: The first time you insert a movie into the DVD/CD-RW tray, you will be prompted to select what you want the system to do when discs are inserted (e.g., start automatically or wait for a prompt). Until you make a selection, you will receive the same prompt whenever you insert a disc.
- 3. Click **OK** to close the About DVD Player Performance dialog box and the movie will begin.

Opening the Media Player Control Panel

With most DVD-ROMs, you have the option of altering how the movie should play and what you wish to view. You can do this by using the media player control panel and the mouse.

- 1. Right-click on the movie screen to open a dropdown menu for options.
- Select View, then Player for all the controls available. This will open the control panel into the bottom of the screen.

Using the Media Player Control Panel

The media player software allows you to watch the movie much like a VCR player. You have the option to pause, rewind, fast-forward and stop the movie at any point.

- 1. To Pause the movie, click the on-screen | button.
- 2. To Rewind the movie, click the ◀ button to rewind to a specific portion of the movie, or the ◄ button to return to the opening screen.

- 3. To Fast-forward the movie, click the >> button to forward to a specific portion of the movie, or the button to jump to the ending credits.
- 4. To Stop the movie, click the button.

Exiting the Media Player

- 1. Click on the X located in the upper right corner of the title bar. This will open a media player dialog
- 2. Click **Yes** to stop and exit the movie, or **No** to close the media player dialog box and return to the movie.

USING DOLBY[™] HEADPHONE

The Dolby Headphone utility lets you enjoy multichannel sound sources, such as DVD movies, with realistic virtual surround sound using conventional stereo headphones. The Dolby Headphone is a utility that is available in the InterVideo WinDVD application.

Dolby Headphone is a signal processing system that enables your stereo headphones to realistically emulate the sound of a five-speaker playback system.



POINT

- Media discs which do not have the Dolby Surround 5:1 symbol will not support Dolby Headphone.
- After making changes to the Dolby Headphone feature and clicking OK, wait at least ten seconds before making another change in order to allow the system to stabilize.

To use the Dolby Headphone feature, perform the following steps:

- 1. Double click the InterVideo WinDVD icon on your
- 2. On the toolbar that appears, click the Properties button (the fourth button from the left, with the image of a wrench).
- 3. On the Properties window, select the Dolby Headphone tab.
- 4. To enable Dolby Headphone, check the Enable Dolby Headphone box. To change the type of surround sound, select one of the radio buttons listed under Room Filter Setting.
- 5. Click OK. The Dolby Headphone feature will now be enabled until you disable it by unchecking Enable Dolby Headphone.

USING THE MEDIA PLAYER ON **BATTERY POWER**

Since media player drives consume a lot of power, your overall battery life will be significantly shorter when operating the media player drive continuously (such as watching a DVD movie) than during standard operation. Many movies run-times are longer than your LifeBook notebook can support on a single charged battery. If you are watching a DVD movie on battery power you may need to swap in an additional, charged battery or attach AC power during the movie to view it in its entirety.



POINT

- Prolonged use of the media player drive, such as watching a DVD movie, will substantially reduce your LifeBook notebook's battery life.
- Many movie run-times are longer than your system can support on a single battery. If you are watching a DVD movie on battery power you may need to swap in an additional, charged battery or attach AC power during the movie to view it in its entirety.
- An additional fully-charged battery is highly recommended if you will be watching DVD movies on battery power. If you don't have an additional battery, you may purchase one either online at www.fujitsupc.com or by calling 1-877-372-3473.

To Watch a Movie on Battery Power:

- 1. Have an additional full-charged battery or your AC adapter ready for use.
- 2. Start watching your DVD movie.
- 3. When the low battery warning occurs, immediately stop the movie and exit the media player.



M CAUTION

If you do not stop the media player quickly and the LifeBook notebook attempts to auto-suspend (critical battery low state) the LifeBook notebook will shut down improperly. If this occurs, you will need to perform a hard reset and follow the instruction, if any, presented to you before the system will reboot.

- 4. Power down your LifeBook notebook and replace the discharged battery with an additional fullycharged battery. If you do not have an additional battery, you may attach AC power as soon as you see the low battery warning.
- 5. Resume your LifeBook notebook by pressing the Suspend button again. This step is not required if you attached AC power without entering suspend mode.
- 6. Restart your media player, locate and skip to the chapter of the movie you were last watching.
- 7. Continue watching your DVD movie.



POINT

Some shorter DVD movies may not require you to swap batteries or attach AC power to complete them. However, it is best to be prepared since actual battery life while operating the media player drive cannot be guaranteed.

AUTO INSERT NOTIFICATION FUNCTION

The Auto Insert Notification function allows your Life-Book notebook to automatically start a DVD/CD as soon as it is inserted in the media player drive and the tray is closed. Your LifeBook notebook will begin playing an audio DVD/CD or will start an application if the DVD/CD includes an auto run file.

Disabling Auto Insert Notification Function

To disable the Auto Insert Notification function, follow these easy steps:

- 1. Save all data and close all open applications.
- 2. From the Start menu, select Settings, and then select Control Panel.
- Double-click the System icon. This will open the System Properties dialog box.
- 4. Select the **Device Manager** tab to display the device lists for your LifeBook notebook.
- Click on the + to the left of the CD player drive icon.
 The treeview will expand to show the media player drive manufacturer's name and model number.
- Double-click on the media player drive manufacturer's name and model number. This will open the media player drive manufacturer's name and model number dialog box.
- Select the Settings tab and then remove the check mark in the Auto Insert Notification box to turn it off.
- 8. Click OK.
- Click Close in the System Properties dialog box, then click Yes in the System Settings Change pop-up window when it asks you to restart your machine and activate this change.

The Auto Insert Notification function can be re-activated by repeating this process and placing a check mark in the Auto Insert Notification box to turn it back on.



POINT

An alternative method for disabling Auto Insert Notification is to hold down the [Shift] key while the CD is loading. This disables the Auto Insert function for the current load. If the CD is removed and reinstalled, the function will again be enabled.




Figure 2-17 Installing a Memory Stick/SD Card

Memory Stick/ **Secure Digital Slot**

Your LifeBook notebook supports Memory Stick and Secure Digital (SD) Cards, on which you can store and transfer data to and from a variety of digital devices. These cards use flash memory architecture, which means they don't need a power source to retain data.

Memory Stick is a flash memory technology developed by Sony Electronics. Memory Stick allows you to record, transfer and share digital content, such as digital pictures, movies, music, voice, and computer data and applications.

Secure Digital (SD) Cards are very similar to Memory Sticks, but they are shorter. Like the Memory Stick, SD Cards allow portable storage among a variety of devices, such as cell phones, GPS systems, digital cameras, and PDAs. SD Cards transfer data quickly, with low battery consumption. Like the memory stick, it uses flash memory architecture.




Figure 2-18 Memory Stick and Secure Digital Card

INSTALLING MEMORY STICK/SD CARDS

Memory Sticks and SD Cards are installed in the Memory Stick/SD Card slot (Figure 2-17). To install a Memory Stick or SD Card, follow these steps:

MARNING

- Installing or removing a Memory Stick or SD Card during your LifeBook notebook's shutdown or bootup process may damage the card and/or your LifeBook notebook.
- Do not insert a card into a slot if there is water or any other substance on the card as you may permanently damage the card, your LifeBook notebook, or both.
- 1. See your Memory Stick or SD Card manual for instructions on the installation of your card. Some cards may require that your notebook is off while installing them.
- 2. Make sure there is no card currently in the slot. If there is, see Removing a Memory Stick/SD Card.
- 3. Insert your PC Card into the slot with the product label facing up.
- 4. Push the card firmly into the slot until it is seated in the connector.

REMOVING A MEMORY STICK/SD CARD

To remove a Memory Stick or SD Card, follow these easy steps:

1. See your Memory Stick or SD Card manual for instructions on the removal of your card. Some cards may require your LifeBook notebook to be in Suspend Mode or Off while removing them.

Optical Digital Audio Out

Your LifeBook notebook has an Optical Digital Audio Out Port to which you can connect an optional Mini-Disc recorder to record music or to a home sound system to play your MP3 files. The optical digital audio out port is located on the right-hand side of your Life-Book notebook.



POINT

MiniDisc recorder operation is dependent upon the individual vendor's instructions. Be sure to thoroughly review any documentation that comes with your player before using your device.

CONNECTING AN OPTICAL DIGITAL CABLE

To connect a minidisc recorder or to a personal sound system, install the cable that came with your recorder as illustrated. Install the connector with the long plug into the player, as instructed in the vendor's user instructions. Connect the other end of the optical digital cable to the Optical Digital Audio Out port on your LifeBook notebook. The Optical Digital Audio Out port is the middle round port on the right-hand side of your LifeBook notebook.



POINT

Certain minidisc recorder cable connectors are configured differently from that illustrated. If your cable connector does not fit properly, you will need to purchase an adapter from a third-party electronics store.




Figure 4-6 Connecting Optical Digital Cable




Figure 4-7 Installing/Removing PC Cards

PC Cards

Your LifeBook notebook supports Type I, Type II and Type III PC Cards, which can perform a variety of functions depending on which type of card you install. You can install one or two PC Cards at a time, depending on its type. Type I/II PC Cards can be installed together, while Type III PC Cards must be installed alone.

Some available PC Cards:

- Fax/data modem cards (Type II)
- Local area network (LAN) cards (Type II)
- IDE solid-state disk cards (Type II)
- SCSI cards (Type II)
- Wireless LAN (802.11b) cards (Type II)
- Hard Drive (ATA) cards (Type III)
- Other PC Cards that conform to PCMCIA 2.1 or CardBus standards

For further information, refer to the instructions supplied with your PC Card.

INSTALLING PC CARDS

PC Cards are installed in the PC Card slot. To install a PC Card(s), follow these easy steps:

A WARNING

- Installing or removing a PC Card(s) during your Life-Book notebook's shutdown or bootup process may damage the card and/or your LifeBook notebook.
- Do not insert a PC Card into a slot if there is water or any other substance on the card as you may permanently damage the card, your LifeBook notebook, or both.



You may be required to log on as an Administrator or a member of the Administrator's Group to complete this procedure. If your computer is connected to a network, network policy settings may also prevent you from completing this procedure.

- 1. See your PC Card manual for instructions on the installation of your card. Some cards may require that your notebook is off while installing them.
- 2. Make sure there is no PC Card currently in the slot. If there is, see Removing PC Cards.
- 3. If either of the eject buttons is extended, press it in until it clicks.
- 4. Insert your PC Card into the slot with the product label facing up.
- 5. Push the card firmly into the slot until it is seated in the connector.

REMOVING PC CARDS


To remove a PC Card(s), follow these easy steps:

 See your PC Card manual for specific instructions on removing your card. Some PC Cards may require your LifeBook notebook to be in Suspend Mode or Off while removing them.



POINT

- Windows has a shutdown procedure for PC Cards that must be followed before removing a card. (Review your operating system manual for the correct procedure.) It is good practice to remove devices using the Unplug or Eject Hardware icon in the system tray.
- If the dialog box states that the device cannot be removed, you must save all of your open files, close any open applications and shut down your notebook. Once your LifeBook notebook has been shut down, you must turn Off the power using the power switch.
- Unlock the card from the slot by pressing the eject button associated with the slot in which the card is located. When pressed, the button will pop out.
- 3. Firmly press the button again until it is flush with the notebook. This will eject the card slightly out of the slot allowing you to remove the card.



If the PC Card(s) has an external connector and cable, do not pull the cable when removing the card.

Memory Upgrade Module

Your LifeBook notebook comes with 256MB of on-board high speed Synchronous Dynamic RAM (SDRAM, PC2100-type, DDR, 266MHz) factory installed. To increase your LifeBook notebook's memory capacity, you may install an additional memory upgrade module. The memory upgrade must be a dual-in-line (DIMM) SDRAM module. To ensure 100% compatibility, purchase the SDRAM module only from the Fujitsu web store at: www.fujitsupc.com.

INSTALLING A MEMORY UPGRADE MODULE

To install a memory upgrade module follow these steps:

MARNING

- Turn off power and remove any telephone line connections before performing the memory upgrade.
- If the computer has been used recently, it may be hot.
 Make sure the system has cooled off completely before changing memory.
- 1. Turn off power to your LifeBook notebook and remove any power adapter (AC or auto/airline) and telephone line connections.
- Place your LifeBook notebook on a clean work surface.
- 3. Open the top cover all the way, so that it is lying flat on the work surface.
- 4. Slide the access cover slightly to the left until it becomes disengaged. Remove it from the system (*Figure 4-8*)



Figure 4-8. Sliding the access cover

WARNING

The memory upgrade module can be severely damaged by electrostatic discharge (ESD). Be sure you are properly grounded when handling and installing the module, and follow ESD precautions noted in the literature that accompanies the memory module.

5. Push the keyboard toward the back of the system until it disengages and can be lifted freely. (*Figure 4-9*)



Figure 4-9. Sliding the keyboard

7. Carefully pivot the front of the keyboard away from the laptop until it is lying on the display. (*Figure 4-10*)




Figure 4-10. Folding the keyboard back

- 8. Align the connector edge of the memory upgrade module, chip side up, with the connector slot in the compartment. (*Figure 4-11*)
- 9. Insert the memory upgrade module at a 45° angle and press it firmly onto the connector.
- 10. Press the memory upgrade module down into the compartment until it locks underneath the retaining clip. You will hear a click when it is properly in place. (Figure 4-11)




Figure 4-11. Inserting a new memory module

11. Carefully flip the keyboard back into its original position, and slide it towards the front of the unit until it is seated. (*Figure 4-12*)



Figure 4-12. Reinstalling the keyboard

12. Replace the access cover you removed in step 4. (*Figure 4-13*) Installation of the new memory module is now complete.



Figure 4-13. Replacing the access cover



POINT

The memory upgrade module is not something you routinely remove from your LifeBook notebook. Once it is installed, you should leave it in place unless you want to increase system memory capacity.

REMOVING A MEMORY UPGRADE MODULE

- 1. Perform steps 1 through 7 of Installing a Memory Upgrade Module.
- 2. Pull the clips sideways away from each side of the memory upgrade module at the same time. (*Figure 4-14*)




Figure 4-14. Removing a memory module

3. While holding the clips out, remove the module from the slot by lifting it up and pulling towards the back of your LifeBook notebook.

- 4. Store the memory upgrade module in a static guarded sleeve.
- 5. Replace the keyboard by following steps 11 and 12 of Installing a Memory Upgrade Module.



POINT

After changing your memory module configuration, you must complete the Resetting the Hibernation (Save-to-Disk) Parameters procedure in order for the Hibernation (Save-to-Disk) mode to operate properly on your LifeBook notebook. (See Hibernation (Save-to-Disk) Feature on page 30 for more information)

CHECKING THE COMPUTER RECOGNITION OF NEW MEMORY CAPACITY

Once you have changed the system memory capacity by either adding or removing a memory upgrade module, be sure to check that your LifeBook notebook has recognized the change.

You can check the memory capacity by looking at the main menu of the BIOS setup:

- 1. Turn on the power to your LifeBook notebook using the power switch.
- 2. Allow the system to start booting and press the F2 key once the Fujitsu logo appears on the screen. This will open the main menu of the BIOS setup with the current settings displayed. (See BIOS Setup Utility on page 27 for more information) Use the right arrow key to select Info in the BIOS Setup menu.

The System Memory and the Extended Memory capacity, as detected by your LifeBook notebook during the Power On Self Test (POST), are displayed at the bottom of the Info menu screen. The chart below shows you the possible displays that can be shown on the main menu screen.



POINT

If the total memory displayed is incorrect, check that your memory upgrade module is properly installed. (If the module is properly installed and the capacity is still not correctly recognized, see the Troubleshooting section starting on page 71)

Installed		Displayed		
On Board	Slot 1	Total RAM Installed	System Memory	Extended Memory
256MB	0	256MB	640K	255MB
256MB	128MB	384MB	640K	383MB
256MB	256MB	512MB	640K	511MB
256MB	512MB	768MB	640K	767MB

Device Ports

Your LifeBook notebook comes equipped with multiple ports to which you can connect external devices including: disk drives, keyboards, modems, printers, etc.

MODEM (RJ-11) TELEPHONE JACK

The modem (RJ-11) telephone jack is used for an internal modem. To connect the telephone cable follow these easy steps: (See figure 2-6 on page 11 for location)

- 1. Align the connector with the port opening.
- 2. Push the connector into the port until it is seated.
- 3. Plug the other end of the telephone cable into a telephone outlet.



WARNING

The internal modem is not intended for use with Digital PBX systems. Do not connect the internal modem to a Digital PBX as it may cause serious damage to the internal modem or your entire LifeBook notebook. Consult your PBX manufacturer's documentation for details. Some hotels have Digital PBX systems. Be sure to find out BEFORE you connect your modem.



POINT

- The internal modem is designed to the ITU-T V.90 standard. Its maximum speed of 53000bps is the highest allowed by FCC, and its actual connection rate depends on the line conditions. The maximum speed is 33600bps at upload.
- The internal modem on all LifeBook notebooks are certified for use in the United States and Canada. The modem may be certified in other countries.

INTERNAL LAN (RJ-45) JACK

The RJ-45 jack is used to connect the internal Fast Ethernet (10/100 Base-T/Tx) to a Local Area Network (LAN) in your office or home, or broadband devices such as a cable modem, DSL, or satellite internet. If your notebook has been configured with internal LAN capability you will need to configure your notebook to work with your particular network. (To properly set up your LAN environment, consult with a networking professional. Please refer to your network administrator for information on your network configuration.) To connect the LAN cable follow these easy steps: (See figure 2-6 on page 11 for location)

- 1. Align the connector with the port opening.
- 2. Push the connector into the port until it is seated.
- 3. Plug the other end of the cable into a LAN outlet.

IEEE 1394 PORT

The 4-pin 1394 port allows you to connect digital devices that are compliant with IEEE 1394 standard. The IEEE 1394 standard is easy to use, connect, and disconnect. This port can allow up to 400 Mbps transfer rate. A third-party application is required to operate your digital device with the 1394 port.



POINT

The 1394 port used in this system uses a four-pin configuration. If you intend to interface with devices which use a six-pin configuration, you will need to purchase an adapter.

In order to connect a 1394 device, follow these steps: (See figure 2-4 on page 9 for location)

- 1. Align the connector with the port opening.
- 2. Push the connector into the port until it is seated.

UNIVERSAL SERIAL BUS PORT

A Universal Serial Bus (USB) 2.0 port allows you to connect USB devices such as game pads, pointing devices, keyboards and speakers. USB 2.0 is downwardcompatible with USB 1.1 devices, so older USB devices will work with these ports. USB 2.0 is a much faster design, running forty times faster than USB 1.1. To connect a USB device follow these steps: (See figure 2-6 on page 11 for location)

- 1. Align the connector with the port opening.
- 2. Push the connector into the port until it is seated.



POINT

Due to the ongoing changes in USB technology and standards, not all USB devices and/or drivers are guaranteed to work.

PARALLEL PORT

The parallel port, or LPT port, allows you to connect parallel devices, such as a printer to your notebook. In order to connect a parallel interface device, follow these steps: (See figure 2-6 on page 11 for location)

- 1. Align the connector with the port opening.
- 2. Push the connector into the port until it is seated.
- Tighten the two hold-down screws, located on each end of the connector.

MICROPHONE JACK

The microphone jack allows you to connect an external mono microphone. Your microphone must be equipped with a 1/8"(3.5 mm) mono mini-plug in order to fit into the microphone jack of your LifeBook notebook. In order to connect a microphone follow these easy steps: (See figure 2-5 on page 10 for location)

- 1. Align the connector with the port opening.
- 2. Push the connector into the port until it is seated.

OPTICAL DIGITAL AUDIO-OUT CONNECTOR

The optical digital audio-out connector allows you to download digital audio to MiniDisc recorders or connect to your sound system to play audio files. It uses SPDIF (Sony Philips Digital Interface) format. Please use the following setting when using the digital audio-out connector. (See figure 2-5 on page 10 for location)

- Click on Start, Settings and then click on Control Panel.
- 2. Select Yamaha Ds-XG Audio Configuration.
- Click on the SPDIF tab and click on Digital Sources Only. If you don't see this setting, the optical digital is always on by default.

POINT

- There are several types of cables for connecting a digital electronic device (e.g., MD player) to the digital audio-out connector, depending on the connector type. The connector on your computer is a Optical Mini Plug (3.5mm diameter mini plug)
- The frequency of the digital sound output from the SPDIF output connector is fixed to 48KHz. If a sampling rate convertor is not installed in your digital electronic device (e.g., MD player), recording is not possible. See the device user manual for more details.
- The sound recorded through connecting a digital electronic device (e.g., MD player) to the SPDIF output connector cannot be used as digital output. All output data from the SPDIF output connector has copyright protection information included.

HEADPHONE JACK

The headphone jack allows you to connect headphones or powered external speakers to your LifeBook notebook. Your headphones or speakers must be equipped with a 1/8" (3.5 mm) stereo mini-plug. In order to connect headphones or speakers follow these easy steps: (See figure 2-5 on page 10 for location)

- 1. Align the connector with the port opening.
- 2. Push the connector into the port until it is seated.



POINT

If you plug headphones into the headphone jack, you will disable the built-in stereo speakers.

S-VIDEO OUT PORT

The S-Video port allows you to connect and use directly any S-Video device, such as a VCR or television. The S-Video standard provides for a higher quality picture than NTSC or PAL. To connect an S-Video device, follow these steps: (See figure 2-4 on page 9 for location)

- 1. Align the connector with the port opening.
- 2. Push the connector into the port until it is seated.

EXTERNAL MONITOR PORT

The external monitor port allows you to connect an external monitor. To connect an external monitor follow these steps: (*See figure 2-6 on page 11 for location*)

- 1. Align the connector with the port opening.
- 2. Push the connector into the port until it is seated.
- 3. Tighten the two hold-down screws, located on each end of the connector.



POINT

Pressing the [Fn] + [F10] keys allows you to change the destination of your display video. Each time you press the key combination, you will step to the next choice, starting with the built-in display panel only, moving to the external monitor only, finally moving to both the built-in display panel and an external monitor.

SERIAL PORT

The serial port allows you to connect serial devices, such as printers or scanners. In order to connect a serial interface device follow these easy steps:

- 1. Align the connector with the port opening. (*See figure 2-6 on page 11 for location*)
- 2. Push the connector into the port until it is seated.
- 3. Tighten the two hold-down screws, located on each end of the connector.

INFRARED PORT

The Infrared IrDA (4Mbps) port allows for wireless data transfer between your notebook and other IrDA-compatible devices, such as another computer or a printer, without the use of a cable. (See figure 2-5 on page 10 for location)

It is important to keep in mind that while carrying out this form of communication, both devices must be placed so their infrared ports are directly facing each other without obstruction. The devices must also be separated by at least 6" but no more than 36" for maximum performance.



POINT

- Do not move either device while communication is active as it may interrupt data transmission.
- Be careful not to scratch the infrared port lens. Dirt, scratches, or other surface marks can degrade operation.

LifeBook C Series Notebook - Section Four

Using the Integrated Wireless LAN*

*Optional device

LifeBook C Series Notebook - Section Five



FCC REGULATORY INFORMATION

Please note the following regulatory information related to the optional wireless LAN device.

Regulatory Notes and Statements

Wireless LAN, Health and Authorization for use

Radio frequency electromagnetic energy is emitted from Wireless LAN devices. The energy levels of these emissions, however, are far much less than the electromagnetic energy emissions from wireless devices such as mobile phones. Wireless LAN devices are safe for use by consumers because they operate within the guidelines found in radio frequency safety standards and recommendations. The use of Wireless LAN devices may be restricted in some situations or environments, such as:

- On board an airplane, or
- · In an explosive environment, or
- In situations where the interference risk to other devices or services is perceived or identified as harmful

In cases in which the policy regarding use of Wireless LAN devices in specific environments is not clear (e.g., airports, hospitals, chemical/oil/gas industrial plants, private buildings), obtain authorization to use these devices prior to operating the equipment.

Regulatory Information/Disclaimers

Installation and use of this Wireless LAN device must be in strict accordance with the instructions included in the user documentation provided with the product. Any changes or modifications made to this device that are not expressly approved by the manufacturer may void the user's authority to operate the equipment. The Manufacturer is not responsible for any radio or television interference caused by unauthorized modification of this device, or the substitution or attachment of connecting cables and equipment other than those specified by the manufacturer. It is the responsibility of the user to correct any interference caused by such unauthorized modification, substitution or attachment. The Manufacturer and its authorized resellers or distributors will assume no liability for any damage or violation of government regulations arising from failure to comply with these guidelines.

Federal Communications Commission statement

This device complies with Part 15 of FCC Rules.

Operation is subject to the following two conditions: (1) This device may not cause interference, and, (2) This device must accept any interference, including interference that may cause undesired operation of this device.

FCC Interference Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy. If not installed and used in accordance with the instructions, it may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try and correct the interference by one or more of the following measures:

- 1. Reorient or relocate the receiving antenna.
- 2. Increase the distance between the equipment and the receiver.
- 3. Connect the equipment to an outlet on a circuit different from the one the receiver is connected to.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Radio Frequency Exposure statement

This Wireless LAN radio device has been evaluated under FCC Bulletin OET 65C and found compliant with the requirements as set forth in CFR 47 Sections 2.1091, 2.1093, and 15.247 (b) (4) addressing RF Exposure from radio frequency devices. The radiated output power of this Wireless LAN device is far below the FCC radio frequency exposure limits. Nevertheless, this device shall be used in such a manner that the potential for human contact during normal operation is minimized. When using this device, a certain separation distance between antenna and nearby persons must be maintained to ensure RF exposure compliance. In order to comply with RF exposure limits established in the ANSI C95.1 standards, the distance between the antennas and the user should not be less than 20 cm (8 inches).

Export restrictions

This product or software contains encryption code which may not be exported or transferred from the US or Canada without an approved US Department of Commerce export license. This device complies with Part 15 of FCC Rules., as well as ICES 003 B / NMB 003 B. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesirable operation. Modifications not expressly authorized by Fujitsu PC Corporation may invalidate the user's right to operate this equipment.

BEFORE USING THIS DEVICE

The Integrated Wireless LAN is an optional device available for the LifeBook C Series laptops. This manual describes the basic operating procedures for the Wireless LAN (referred to as the "device" in this manual) and how to set up a wireless LAN network. Before using this device, read this manual carefully to ensure correct operation of the device. Keep this manual in a safe place for reference while using the device.

Characteristics of the Device

This device consists of a wireless LAN card that is attached to the computer via a mini-PCI slot.

The main characteristics are as follows:

- It uses the power saving communications system in the 2.4 GHz band, and does not require any license for radio communication.
- It uses Direct Sequence Spread Spectrum (DS-SS), which is resistant to noise.
- This device complies with Wi-Fi, and is able to communicate at the maximum transfer rate of 11 Mbps.
- The maximum communication range is approximately 80 feet (25 meters) inside a building. The range may be shorter depending upon the installation factors, such as walls and columns.
- Unauthorized access can be prevented with the use of SSID and encryption key.

Wireless LAN Modes Using this Device

AdHoc Mode

The "AdHoc Mode" refers to the network connecting two computers using wireless LAN cards. This connection is called an "AdHoc network."

Using an AdHoc network, you can obtain a network connection easily and at a low cost.

In the AdHoc mode, you can use the function supported by Microsoft Network, such as File and Print Sharing to exchange files and share a printer or other peripheral devices.

To use the AdHoc Mode, you must set the same SSID and the same encryption key for all the computers that are connected. All connected computers can communicate with each other within the communication range.

Infrastructure Mode

If a number of computers are connected simultaneously in the AdHoc mode, the transfer rate may be reduced, communications may become unstable, or the network connection could fail. This is because all wireless LAN cards are using the same radio frequency in the network.

To improve this situation, you can use a wireless LAN access point, which is sold separately. The wireless LAN network is in the "Infrastructure mode" when it uses an access point, and such a connection is called the "Infrastructure Network."

By using an access point, you can set and use a different communication channel for each network group. Each channel is given a different radio frequency, and it eliminates the collision of communications and provides a more stable communications environment. Infrastructure mode is most suitable when you are configuring multiple wireless LAN networks on the same floor.

To connect a wireless LAN network to a wired LAN, you need an access point.

How to Handle This Device

The optional integrated Wireless LAN device is already installed in your LifeBook computer. Under normal circumstances, it should not be necessary for you to remove or re-install it. The LAN has been configured to support the operating system with which your system shipped.

CONNECTING WINDOWS 2000 SYSTEMS

This chapter describes how to set the wireless LAN connection for computers running Windows 2000.



POINT

If you purchased a LifeBook with the optional integrated wireless LAN device, the device and drivers have already been installed. This procedure outlines the steps for setting the device parameters.

Updated drivers and/or utilities may become available after this manual is printed; see any addenda or fliers that may be included in the system packaging.

Workflow

The proper setup of the wireless LAN requires several steps which must be performed in the proper order. Following is a general outline of the steps that must be performed. Each step is detailed later in this procedure.

- 1. Setting parameters
 - Setting the profile
 - Setting the encryption
- 2. Network settings
 - Setting the protocol and checking the network
 - Setting file and printer sharing
 - Checking the connection

Setting Parameters

- 1. Click [Start] -> [Settings] -> [Control Panel].
- 2. Double-click the [PRISM Settings] icon. The [PRISM Wireless Settings] appears.
- 3. Set the profile as specified in Table 3. Ask your network administrators to check the setting.
- 4. When you finish your entry, click [Apply].

Item	Description
Profile	Enter the system file name in which the parameter information is to be saved.
Mode	Ad Hoc Network: Click the down arrow and select "802.11 AdHoc".
	Infrastructure Network: Click the down arrow and select "Infrastructure".
SSID	Enter the network name to which you want to connect
Transmit Rate	Obtain the information from your network administrator. If you do not have a network administrator, select "Fully Automatic".

Item	Description
Power Save Enabled	Not supported.
AdHoc Channel	AdHoc Network: Select the same channel, 1-11, for all connected computers. If there is more than one wireless LAN nearby (such as on the same floor), we recommend that the channels for each LAN be 5 numbers apart (e.g., if there are two other LANs nearby, the channels used should be 1, 6, and 11). Infrastructure Network: Not an option.

Table 3: Profile Parameters

- 5. Click the [Encryption] tab.
- 6. Set the encryption items in accordance with Table 4.
 - AdHoc Network: Specify the same value for all the computers for which the encryption key is used for connection.
 - Infrastructure Network: Specify the identical encryption keys to the encryption keys set for the access point. For instructions on how to check the encryption keys set for the access point, refer to the access point manual.



POINT

Make sure that you specify the encryption keys. If you do not specify the keys, any computer with a wireless LAN card can be connected. This presents a risk that your data may be stolen or destroyed.

Item	Description
Encryption (WEP)	Click the down arrow and select an encryption option.
	Disable: Disables the encryption. In this case, "Create keys with Passphrase" and subsequent items are greyed out, and you cannot enter anything.
	40 bit*: The encryption is set. Select either "Create keys with Passphrase", "Create keys manually", or "ASCII Input", and enter the encryption keys.
	■ 104 bit*: The encryption is set. Select either "Create keys with Passphrase", "Create keys manu- ally", or "ASCII Input", and enter the encryption keys.

Item	Description
Create Keys with Passphrase	Not supported.
Passphrase	Not supported.
Create Keys Manually (Hexadecimal Input)	Select this to use hexadecimal character codes to set the encryption keys (Keys 1 - 4).
	Enter a 10-digit value when you have selected [40 bit]* for the encryption. Enter a 26-digit value when you have selected [104 bit]* for encryption.
	Select if the network contains a card that is set with the encryption key using the character code. Specify the encryption keys with the same value used for other wireless LAN cards that are already set.
ASCII Input	Select to use the ASCII codes to set encryption keys (Keys 1 - 4). Select this if network does not contain other wireless LAN cards that are set with encryption key using character codes.
	Enter a 5-digit value when you have selected [40 bit]* for the encryption. Enter a 13-digit value when you have selected [104 bit]* for encryption.
	You can use the following characters: 0 - 9, A - Z, a - z, _ (underscore).
	For example, to set "ABC12" for the encryption key, enter "ABC12."
Default Key	Click the down arrow, and select a key from Keys 1 - 4.

Table 4: Encryption Key Setup

- 7. When you finish your entry, click [Apply].
- 8. Click [OK]. [PRISM Wireless Settings] closes. You have completed the parameter settings.

4

POINT

When using ADSL (PPPoE) with the infrastructure network to connect to the Internet, you must change the computer's MTU size set. To change MTU size, refer to the manual that comes with the access point.

* 40 bit and 104 bit encryption is the wireless LAN equivalent of 64 bit and 128 bit encryption, as set by Microsoft and wireless LAN manufacturers. This is the same encryption rate that is used by the Windows XP operating system, and was selected in order to align it

closer to the wireless LAN standard. For consistency, the Windows 2000 utilities reflect the same modes.

Outside of wireless LAN environments, encryption is generally set at either 64 bit or 128 bit. However, the wireless LAN standard requires that 24 bits be reserved for fixed data. As a result, the user can only use 40 bits (64 minus 24) or 104 bits (128 minus 24) for encryption. This requirement also fixes the number of characters used for 128 bit encryption to 13 which is calculated as (13 x 8 bits = 104).

NETWORK CONNECTION: WINDOWS 2000

The section describes how to set the network connection for a computer with Windows 2000.

Network Settings

In this section, you set "TCP/IP Settings," and complete "Checking Computer Name and Workgroup," required for the network connection.

TCP/IP Settings

- 1. Click [Start] -> [Settings] -> [Control Panel].
- Double-click the [Network and Dial-up Connections] icon. The [Network and Dial-up Connections] window appears.
- 3. Right click the [Local Area Connection], then click [Properties] from the menu that appears. The [Local Area Connection Properties] window appears.



POINT

More than one network adapter is installed in your system if more than one [Local Area Connection] entry is displayed. In this case, select the [Local Area Connection] entry with [Intersil PRISM Wireless LAN PCI Card] displayed under [Device Name].

- 4. Perform the following steps.
 - Click [Internet Protocol (TCP/IP)].
- Click [Properties]. The [Internet Protocol (TCP/IP)
 Properties] window appears.
- 5. Set an IP address as indicated in Table 5. Ask your network administrator to check the setting.

Item	Description
For AdHoc Network	Set the IP address and subnet mask:
	Click [Use the following IP address], and enter a value for [IP address] and [Subnet mask].
	Refer to "About IP Addresses" on page 67 to set an IP address and subnet mask.
For Infrastructure Network	Select [Obtain an IP address automatically]:
	For the DNS server, select [Obtain DNS server address automatically].
	For the IP address, DNS server, and default gateway, follow the network administrator's instructions, if any.

Table 5: Setting an IP Address

- 6. Click [OK]. The [Local Area Connection Properties] window appears again.
- 7. Click [OK]. When a message appears prompting you to restart the computer, click [Yes].

Checking the full computer name and workgroup

- 1. Click [Start] -> [Settings] -> [Control Panel].
- 2. Double-click the [System] icon. [System Properties] appears.
- 3. Click the [Network Identification] tab.
- Check [Full computer name] and [Workgroup]. Ask your network administrator and check the setting.

Item	Description
Full Computer Name	A name to identify the computer on the network. You can specify any name to each computer.
	For easier identification, use the model name or user name.
Workgroup	A name for the network group:
	 AdHoc Network: Specify the same name to all computers within the same network.
	 Infrastructure Network: Specify a workgroup name to connect to.
	To change a setting, click [Properties], and follow the instructions on the screen. [System Properties] appears.

Table 6: Checking computer name and workgroup

5. Click [OK]. When a message appears prompting you to restart the computer, click [Yes].

Sharing

In this section, you set sharing of the drive, folder, and printer.

You only need to set this when you are sharing files or a printer with other computers on the network.

When you share a drive, folder, or printer, you can use them from any computer on the network.

Setting [File and Printer Sharing for Microsoft Networks]

- 1. Click [Start] -> [Settings] -> [Control Panel].
- Double-click the [Network and Dial-up Connections] icon. The [Network and Dial-up Connections] windows appears.
- Right click the [Local Area Connection], then click [Properties] from the menu that appears. [Local Area Connection Properties] appears.



POINT

More than one network adapter is installed in your system if more than one [Local Area Connection] entry is displayed. In this case, select the [Local Area Connection] entry with [Intersil PRISM Wireless LAN PCI Card] displayed under [Device Name].

4. If [File and Printer Sharing for Microsoft Networks] is displayed in the list, make sure that it is checked. If it is not checked, check it and click [OK]. You do not have to perform the following steps. Go to the next section, entitled "Sharing Files."

If [File and Printer Sharing for Microsoft Networks] is **not** found in the list, click [Install], and perform Step 5 and subsequent steps. When you click [Install], the [Select Network Component Type] window appears.

- 5. Perform the following steps.
 - Click [Service].
 - Click [Add]. The [Select Network Service] window appears.
- 6. Perform the following steps.
 - Click [File and Printer Sharing for Microsoft Networks].
 - Click [OK]. You will go back to [Local Area Connection Properties], and [File and Printer Sharing for Microsoft Networks] is added to the list.
- 7. Click [OK].



POINT

If you have changed the setting, [Close] is shown instead. Click [Close].

Sharing Files

The following example shows how to set sharing the "Work" folder on the c: drive.

- On the desktop, double-click [My Computer] ->
 C: drive.
- Right-click the "Work" folder, then click [Sharing] from the menu. The [Work Properties] window appears.
- 3. Click [Share this folder] and set necessary items, as indicated in the following table.

Item	Description
Share name	You can specify a share name for the drive or folder that you want to share.
Comment	You can enter the description for the drive or folder that you want to share.
User limit	Specifies the limit for the number of sharing users.
Permissions	Specifies the folder access privileges.
Caching	Specifies the caching for the folder.

Table 7: Sharing files

4. Click [OK]. The folder is set shared, and the "Work" folder icon changes.

Printer Sharing

- Click [Start] -> [Settings] -> [Printers]. The Printers window appears, showing the printers that are connected.
- 2. Right click the printer that you want to share, then click [Sharing] from the menu that appears.
- 3. Click [Sharing], and select necessary items.

Item	Description
Not Shared	Disables printer sharing.
Shared As	Enables printer sharing.
Share Name	Specifies a share name of the printer to be shared.

Item	Description
Comment	Enter the description of the printer to be shared.
Passwords	If you specify a password, you need to enter it when using the printer.

Table 8: Printer Sharing

4. Click [OK]. The printer sharing is set, and the icon changes.

Checking the Connection

After the network setting is completed, access the shared drive on another computer to check the connectivity of the wireless LAN network.

Accessing Another Computer

- 1. Double-click the [My Network Places] icon on the desktop. [My Network Places] appears.
- 2. Double-click [Computers near me]. The computers that are connected to the network are displayed.
- Double-click the computer that you want to access. The drive that you set with "Sharing" are displayed.
- 4. Double-click the drive that you want to access. The drive is displayed showing its contents and made available to you. If you have any questions or problems, refer to "Troubleshooting" on page 63.

Checking the Connectivity

- 1. Click [Start] -> [Settings] -> [Control Panel].
- 2. Double-click the [PRISM Settings] icon. [PRISM Wireless Settings] appears.
- 3. Check the connectivity on the [Link] tab. The current condition of connection is displayed.

Item	Description
State	Shows the current condition of connection.
	The MAC address of the other computer to which you are connected is displayed when the connection is successful. If you are connected to more than one computer, the computer that has the best connectivity is displayed.
Current Channel	Shows the current channel used for the connection.
Current Tx Rate	Shows the current transfer rate in Mbits/sec.

Item	Description
[Radio Off]/ [Radio On]	Click [Radio Off] to disconnect.
	Click [Radio On] to connect to the network.
[Rescan] button	Click this button to search for others to connect to.
Throughput (Bytes/sec)	Shows the actual transfer rate of the data transfer for send (Tx) and receive (Rx).
Link Quality	Shows either [Excellent], [Good], [Fair], [Poor], or [Not Connected], depending on the link quality. Not shown for AdHoc connection.
Signal Strength	Shows either [Excellent], [Good], [Fair], [Poor], or [Not Connected], depending on the signal strength. Not shown for AdHoc connection.

Table 9: Checking connectivity

CONNECTING WINDOWS XP SYSTEMS

This chapter describes how to set up the wireless LAN connection for computers that are running Windows XP.



POINT

If you purchased a LifeBook with the optional integrated wireless LAN device, the device and drivers have already been installed. This procedure outlines the steps for setting the device parameters.

Updated drivers and/or utilities may become available after this manual is printed; see any addenda or fliers that may be included in the system packaging.

Workflow

The proper setup of the wireless LAN connection requires that several steps be performed in the proper order. Following is a general outline of the steps to be performed. Each step is detailed later in this procedure.

- 1. Setting parameters
- Setting the profile
- Setting the encryption
- 2. Network settings
 - Setting the protocol and checking the network
 - Setting file and printer sharing
 - Checking the connection

Setting Parameters

- 1. Click [Start] -> [Control Panel].
- 2. Click [Network and Internet connection].
- 3. Click [Network connection]. A list of networks that are currently installed is displayed.
- 4. Right click [Intersil PRISM Wireless LAN PCI Card] in the list, and click [Properties] from the menu that is displayed. [Wireless Network Connection 2 Properties] appears.
- 5. Click the [Wireless Networks] tab. The [Wireless Networks] tab appears.
- 6. Perform the following steps.
 - Make sure that [Use Windows to configure my wireless network settings] is checked.
 - Click [Add] under [Preferred networks]. [Wireless Network Properties] appears.
- 7. Set parameters.
 - For the AdHoc network, specify the same value to all the computers, for which the encryption key is used for connection.
 - For the infrastructure network, specify the encryption key (network key) with the same value to the encryption key of the access point. For how to check the encryption keys set for the access point, refer to the manual supplied with the access point.



POINT

Be sure to specify the encryption keys. If you do not specify the keys, any computer with a wireless LAN card can be connected. This presents a risk that other users may steal or destroy your data.

Item	Description	
Network Name SSID	Enter the network name to which you want to connect. This is a required item. For the network name, ask your LAN administrator.	
	AdHoc network: Set the same name fo of the computers that are to be connected.	
	Infrastructure network: Specify the same name as that specified on the access point that is to be connected. For access point instructions, refer to the manual that comes with the access point.	
Key Format	Click the down arrow and select the input for the Network key.	
	ASCII characters	Select this when using ASCII characters for the Network Key. Characters that can be used follow:
		0-9, A-Z, a-z, and _ (underscore)
		Example: To set the key to "ABC12", input "ABC12".
	Hexa- decimal characters	Select this when using hexadecimal characters for the Network Key.
		Use this if there is a wireless LAN card in the network that has the Network Key set to a character code. In 'Network Key', input the same value as the other wireless LAN card.

Table 10: Setting parameters

- 8. When you finish your entry, click [OK]. [Wireless Network Connection 2 Properties] appears again.
- 9. Make sure the network name you specified for the SSID in Step 7 is added under [Preferred networks].

Network Connection

The section describes how to set the network connection for a computer running Windows XP.

Network Settings

In this section, you set "TCP/IP Settings," and complete "Checking Computer Name and Workgroup" required for the network connection.

TCP/IP Settings

 On [Wireless Network Connection Properties], click [General].



POINT

If [Wireless Network Connection 2 Properties] is not displayed, click [Start] -> [Settings] -> [Control Panel], and double-click the [Network Connection] icon.

Right click the [Wireless Network Connection], and then click [Properties] from the menu that appears.

- 2. Perform the following steps.
 - Click [Internet Protocol (TCP/IP)].
 - Click [Properties]. [Internet Protocol (TCP/IP) Properties] appears.
- 3. Set an IP address. Ask your network administrator and check the setting.

Item	Description
AdHoc Network	Set the IP address and subnet mask. Click [Use the following IP address]. Enter a value for [IP address] and [Subnet mask]. See "About IP Addresses" on page 67 to set IP address and subnet mask.
For Infrastructure Network	Select [Obtain an IP address automatically]. For the DNS server, select [Obtain DNS server address automatically]. For the IP address, DNS server, and default gateway, follow the network administrator's instructions, if any.

Table 11: Setting an IP address

5. Click [OK].



POINT

If you have changed the setting, [Close] is shown instead. Click [Close].

6. Close [Network Connection].

Checking the Full Computer Name and Workgroup

1. Click [Start] -> [Control Panel]. Make sure the Classic View is selected.

- 2. Double-click the [System] icon. [System Properties] appears.
- 3. Click the [Computer Name] tab.
- 4. Check [Full computer name] and [Workgroup]. Ask your network administrator and check the setting.

Item	Description
Computer Name	A name to identify the computer on the network. You can specify any name to each computer. Use up to 15 single-byte characters. For easier identification, use the model name or user name.
Workgroup	A name of the network group. Use up to 15 single-byte characters.
	AdHoc Network: Specify the same name to all computers within the same network.
	Infrastructure Network: Specify workgroup name to connect to.

Table 12: Setting computer name and workgroup

To change the setting, click [Change], and follow the instructions on the screen. [System Properties] appears again.

5. Click [OK]. When a message appears prompting you to restart the computer, click [Yes].

Sharing

In this section, you set sharing of the drive, folder, and printer.

You need to set this only when you are sharing files or a printer with other computers on the network.

When you share a drive, folder, or printer, you can use these from any computer on the network.

Setting [File and Printer Sharing for Microsoft Networks]

- Click [Start] -> [Control Panel]. Make sure the Classic View is selected.
- 2. Double-click the [Network Connection] icon.
- 3. Right click the [Wireless Network Connection], and then click [Properties] from the menu that appears. [Wireless Network Connection Properties] appears.
- 4. If [File and Printer Sharing for Microsoft Networks] is displayed in the list:
 - Make sure that it is checked. If it is not checked, check it, and click [OK]. You do not have to perform

the following steps. Go to the next section, "Sharing Files."

If [File and Printer Sharing for Microsoft Networks] is **not** found in the list, click [Install], and perform Step 5 and the subsequent steps. When you click [Install], [Select Network Component Type] appears.

- 5. Perform the following steps.
 - Click [Service].
 - Click [Add]. [Select Network Service] appears.
- 6. Perform the following steps.
 - Click [File and Printer Sharing for Microsoft Networks].
- Click [OK]. You will go back to [Wireless Network Connection 2 Properties], and [File and Printer Sharing for Microsoft Networks] is added to the list.
- 7. Click [Close].

Sharing Files

The following example shows how to set sharing the "Work" folder on the c: drive.

- 1. Click [Start] -> [My Computer].
- 2. Double-click the [Local Disk (c:)] icon.
- 3. Right click the "Work" folder, and then click [Sharing and Security] from the menu that appears. [Work Properties] appears.
- 4. Click [If you understand the security risks but want to share files without running the wizard, click here].



POINT

If you have already clicked [If you understand the security risks but want to share files without running the wizard, click here], this window does not appear.

In the [Work Properties] window, the description under [Network Sharing and security] changes.

- Check [Share this folder on the network].Uncheck [Allow network users to change my files], if the shared folder is for read only.
- Click [OK]. The folder is set shared, and the "Work" folder icon changes.

Printer Sharing

- Press [Start] -> [Control Panel] (or [Settings], if viewing in Classic mode) -> [Printers and Faxes].
 The Printers and Faxes display will appear and the connected printers will be displayed.
- 2. Right-click the printer to be shared, and click [Sharing] from the menu that appears. The properties of the printer to be shared will be displayed. Set printer sharing.

On the display, the printer sharing setting is recommended by the Network Setup Wizard, but for the wireless LAN network, security is maintained by network name (SSID) or network key. The following steps allow you to set up printer sharing without using the Network Setup Wizard.

- Click 'If you understand the security risks but want to share printers without running the wizard, click here. 'Enable Printer Sharing' will be displayed.
- 4. Select 'Just enable printer sharing'.
- 5. Click 'OK'. The printer properties will be indicated.
- 6. Select 'Share this printer'.
- 7. Enter the sharing printer name in 'Share name'.
- 8. Click OK. The printer will be shared, and the printer icon will become a sharing icon.

Checking the Connection

After the network setting is completed, access the shared drive on another computer to check the connectivity of the wireless LAN network.

Accessing Another Computer

- 1. Click [Start] -> [My Computer].
- From the left menu in [Other Places], click [My Network Places].
- From the left menu in [Network Tasks], click [View workgroup computers]. The workgroup in which you are participating will appear.
- 4. Double click the computer to which you want to connect. The drive that you set in [Computer Sharing] appears.
- 5. Double click the drive to which you want to connect.

 The contents of the drive will appear, and is available for use

If you have a question or problem, refer to "Trouble-shooting" on page 63.

Checking the Connectivity

- 1. Click [Start] -> [Control Panel].
- 2. Double-click the [PRISM Settings] icon. [PRISM Wireless Setting] appears.
- 3. Check the connectivity on the [Link] tab. The current condition of connection is displayed.

Item	Description	
State	Shows the current condition of connection.	
	The MAC address of the other computer that you are connected to is displayed, when the connection is successfully made. If you are connected to more than one computer, the computer that has the best connectivity is displayed.	
Current Channel	Shows the current channel used for the connection.	
Current Tx Rate	Shows the current transfer rate in Mbits/sec.	
Radio Off/	Click [Radio OFF] to disconnect.	
Radio On	Click [Radio On] to connect to the network.	
Rescan	Click this button to search for others to connect to.	
Throughput (Bytes/sec)	Shows the actual transfer rate of the transfer data for send (Tx) and receive (Rx).	
Link Quality	Shows the link quality. This is not shown for the AdHoc connection.	
Signal	Shows the signal strength.	
Strength	This is not shown for the AdHoc connection.	

Table 13: Checking connectivity

TROUBLESHOOTING

This section contains troubleshooting information, including causes and actions, for problems you may find while using this device.

Troubleshooting Table

Problem	Possible Cause	Possible Solution
An exclamation mark (!) or cross (x) is attached to [Intersil PRISM Wireless LAN PCI Card].	A failure to recognize the device.	Restart the computer.
	A failure in installing the driver.	Restart the computer.
Other computers are not displayed when the [Network	The network has not been set up correctly.	Check the setting for the protocol, workgroup, and sharing. To check this, you need a different procedure, depending upon the
Computer] icon is double-clicked.		operating system that you use. Refer to the appropriate section of this chapter.
	It takes time before	Perform the following steps to search for the computer.
	the network is searched and the computer connected is displayed.	 Click [Start] -> [Search] -> [Other Computers]. Enter the computer name that you are connecting to in [Name], and click [Search]. Double-click the icon of the computer that has been searched.
	A failure in installing the driver.	Make sure that the driver is correctly installed.
	The TCP/IP protocol is not installed, or, the IP address is not set correctly.	Make sure that the TCP/IP protocol is installed. To check this, you need a different procedure, depending on the operating system that you use. Refer to the appropriate section of this manual.
	The TCP/IP protocol is not installed, or, the IP address is not set correctly.	If the TCP/IP protocol is installed, do the following to check the IP address: 1. Windows 2000: Click [Start] -> [Programs] -> [Accessories] -> [Command Prompt]. Windows XP: Click [Start] -> [All Programs] -> [Accessories] -> [Command Prompt].
		 Enter "IPCONFIG" command, and press [Enter]. (If your hard disk is C drive, enter C:\>ipconfig)
		Check that the IP address is correctly displayed under the IP Address.
		Example:
		IP address: 10.0.1.3
		Subnet Mask: 255.255.255.0
		Default Gateway: 10.0.1.1
	No communication due to poor radio signal.	Shorten the distance between computers or remove visible obstacles between them, and retry the connection.

Problem	Possible Cause	Possible Solution
IP packet isn't reaching its destination	Run the PING command to check	Perform the following steps to run the PING command to check if the IP packet is correctly delivered to the destination.
the co	the connection	To run the PING command, the TCP/IP protocol must be installed. First you will determine your IP address, then you will make sure your IP address can respond, and then you will make sure other computers can be addressed.
		 Windows 2000: Click [Start] -> [Programs] -> [Accessories] -> [Command Prompt]. Windows XP: Click [Start] -> [All Programs] -> [Accessories] -> [Command Prompt]. Type: ipconfig > directory\filename
		where directory and filename represent the location at which you want to store the IP information.3. Click [Enter], then go to the location you specified above. The IP
		 address for your system will be contained in the file. To check that your IP address is functioning properly, go back to the DOS prompt and type: ping <your address="" ip="">, then press [Enter]. You will receive several replies, followed by the PING statistics (similar to below).</your>
		 To check that your system is communicating with other systems, go to the DOS prompt and type: \>ping XXX.XXX.XXX.XXX. (With the destination IP address in place of XXX.XXX.XXXX). Example: if the destination IP address is 10.0.1.3:
		C:\>ping 10.0.1.3
		A message similar to the following appears if the connection is successful.
		Pinging 10.0.1.3 with 32 bytes of data:
		Reply from 10.0.1.3: bytes=32 time=1ms TTL=32
		Reply from 10.0.1.3: bytes=32 time<10ms TTL=32
		Reply from 10.0.1.3: bytes=32 time=4ms TTL=32
		Reply from 10.0.1.3: bytes=32 time<10ms TTL=32
		If the connection fails, [Request timed out], [Destination host unreachable], or a similar message appears. In this case, refer to the "Other computers are not displayed" portion of this chapter.
the network possible listed to Refer to specific manual	There are several	The following causes are possible. Check each one of them.
	possible causes, as listed to the right. Refer to the specific section of this manual or your user's manual.	 The network name or encryption key is not right. The driver has not correctly started. The destination computer is not turned on. You do not have the access privilege to the destination computer. The card has failed. Hardware conflict.

Problem	Possible Cause	Possible Solution
I want to remove the driver (Windows 2000)		Windows 2000: When removing the driver, make sure that the device is attached to the computer. If you try to remove the driver while the device is detached from the computer, the driver is not removed.
		Right click the [My Computer] icon on the desktop, and then click [Properties] from the menu that appears. [System Properties] appears.
		2. Click the [Hardware] tab.
		Click [Device Manager]. The [Device Manager] window appears.
		4. Click [+] beside [Network adapters].
		Right click [Intersil PRISM Wireless LAN PCI Card], and click [Uninstall] from the menu that is displayed. [Confirm Device Removal] appears.
		6. Click [OK].
		7. Close [System Properties].
		8. Make sure that the icon has disappeared from the task tray in the lower right corner of the screen.
		9. Click [Start] -> [Settings] -> [Control Panel].
		10. Double-click [Add/Remove Programs]. [Add/Remove Programs] appears.
		11. Perform the following steps.
		Click [PRISM 11Mbps Wireless LAN for Windows].Click [Change/Remove].
		A window appears asking you if you really want to remove the driver.
		12. Click [Yes].
		When the driver is removed, a window appears showing that the driver has been removed.
		13. Click [OK].
		14. Close [Add/Remove Programs] and [Control Panel].
		15. Shut down Windows, and turn off the computer.

Problem	Possible Cause	Possible Solution
I want to remove the driver (Windows XP)		Windows XP: When removing the driver, make sure that the device is attached to the computer. If you try to remove the driver while the device is detached from the computer, the driver is not removed.
		Click [Start], right click [My Computer], and then click [Properties] from the menu that appears. [System Properties] appears.
		2. Click the [Hardware] tab.
		3. Click [Device Manager].
		4. Click [+] beside [Network adapters].
		5. Right click [Intersil PRISM Wireless LAN PCI Card], and click [Uninstall] from the menu that is displayed. [Confirm Device Removal] appears.
		6. Click [OK].
		7. Close [System Properties].
		8. Make sure that the icon has disappeared from the task tray in the lower right corner of the screen.
		9. Click [Start] -> [Control Panel]. [Control Panel] appears.
		10. Double-click [Add/Remove Programs]. [Add/Remove Programs] appears.
		11. Perform the following steps.
		Click [PRISM 11Mbps Wireless LAN for Windows].Click [Change/Remove].
		A window appears asking you if you really want to remove the driver.
		12. Click [Yes].
		When the driver is removed, a window appears showing that the driver has been removed.
		13. Click [OK].
		14. Close [Add/Remove Programs] and [Control Panel].
		15. Shut down Windows, and turn off the computer.

ABOUT IP ADDRESSES

Setting IP Addresses

If you are not sure how to set the IP address, refer to the following procedure.

If you have an access point (DHCP server) on the network, set the IP address as follows:

Windows 2000: [Obtain an IP address automatically]

Windows XP: [Obtain an IP address automatically]



POINT

A DHCP server is a server that automatically assigns IP addresses to computers or other devices in the network. There is no DHCP server for the AdHoc network.

If the IP address is already assigned to the computer in the network, ask the network administrator to check the IP address to be set for the computer.

If no access point is found in the network:

An IP address is expressed with four values in the range between 1 and 255.

Set the each computer as follows: The value in parentheses is a subnet mask.

<Example>

Computer A: 192.168.100.2 (255.255.255.0)

Computer B: 192.168.100.3 (255.255.255.0)

Computer C: 192.168.100.4 (255.255.255.0)

:

Computer X: 192.168.100.254 (255.255.255.0)

SPECIFICATIONS

Technical Specifications for Integrated Wireless LAN Device

Item	Description
Network Type	IEEE 802.11b
Transfer Rate	11/5.5/2/1Mbps (auto change)
Frequency Range	2,400 - 2,473 MHz
Channels	One of 11 channels is used
Card Type	Non-intelligent
VCC	Class B
Security	Network name, encryption key
Supported Operating Systems	Windows 2000, Windows XP
Power Current	Max: 350mA
Maximum number of units recommended for wireless LAN (AdHoc network)	10 or less

LifeBook C Series Notebook - Section Six

Your LifeBook notebook is sturdy and subject to few problems in the field. However, you may encounter simple setup or operating problems that you can solve on the spot, or problems with peripheral devices, that you can solve by replacing the device. The information in this section helps you isolate and resolve some of these straightforward problems and identify failures that require service.

FUJITSU SERVICE ASSISTANT

The LifeBook notebook includes a sophisticated, full-featured troubleshooting tool that can assist you in solving most problems you might encounter. The Fujitsu Service Assistant is an interactive support tool that provides automated diagnosis and solutions for your hardware and software problems. To use this tool, load the Fujitsu Service Assistant CD that was included with your system's accessories, and follow the instructions after the Fujitsu Service Assistant CD launches.

New support information for the Fujitsu Service Assistant tool may be available after the purchase of your notebook. You should periodically connect to the Internet while using the Fujitsu Service Assistant tool to ensure that you are using the most current version.

IDENTIFYING THE PROBLEM

If you encounter a problem, go through the following procedure before pursuing complex troubleshooting:

- 1. Turn off your LifeBook notebook.
- 2. Make sure the AC adapter is plugged into your Life-Book notebook and to an active AC power source.
- Make sure that any card installed in the PC Card slot is seated properly. You can also remove the card from the slot, thus eliminating it as a possible cause of failure.
- 4. Make sure that any devices connected to the external connectors are plugged in properly. You can also disconnect such devices, thus eliminating them as possible causes of failure.
- 5. Turn on your LifeBook notebook. Make sure it has been off at least 10 seconds before you turn it on.
- 6. Go through the boot sequence.
- 7. If the problem has not been resolved, refer to the Troubleshooting Table, that follows, for more detailed troubleshooting information.

POINT

- If you keep notes about what you have tried, your support representative may be able to help you more quickly by giving additional suggestions over the phone.
- Do not return a failed LifeBook notebook to your supplier until you have talked to a support representative
- 8. If you have tried the solutions suggested in the Troubleshooting Table without success, contact your support representative:

Toll free: 1-800-8Fujitsu (1-800-838-5487)

Fax: 1-901-259-5700

E-mail: 8fujitsu@fujitsupc.com Web site: http://www.fujitsupc.com.

Before you place the call, you should have the following information ready so that the customer support representative can provide you with the fastest possible solution:

- Product name
- Product configuration number
- Product serial number
- Purchase date
- Conditions under which the problem occurred
- Any error messages that have occurred
- Hardware configuration
- Type of device connected, if any

See the Configuration Label on the bottom of your LifeBook notebook for configuration and serial numbers. (*See figure 2-7 on page 12 for location*)

SPECIFIC PROBLEMS

Using PC-Doctor

PC-Doctor is a diagnostic program by PC-Doctor.com, Inc., which comes pre-installed on your LifeBook notebook. If you are an experienced computer user you may find it useful, however, it is intended primarily to help your Fujitsu support representative better serve you.

Using the Troubleshooting Table

When you have problems with your LifeBook notebook, try to find the symptoms under the Problem column of the troubleshooting table for the feature giving you difficulty. You will find a description of common causes for that symptom under the column Possible Cause and what, if anything, you can do to correct the condition under Possible Solutions. All possible causes or solutions may not apply to your LifeBook notebook.

TROUBLESHOOTING TABLE

Problem	Page	Problem	Page
Audio Problems	. page 72	USB Device Problems	page 74
Media Player Drive Problems		PC Card Problems	page 75
Floppy Disk Drive Problems		Power Failures	page 75
Hard Drive Problems		Shutdown and Startup Problems	page 77
Keyboard or Mouse Problems		Video Problems	page 78
Memory Problems		Miscellaneous Problems	
Modem Problems	nage 74		

Problem	Possible Cause	Possible Solutions	
Audio Problems			
There is no sound coming from the built-	The software volume control is set too low.	Adjust the sound volume control settings in your software, operating system and applications.	
in speakers.	Headphones are plugged into your LifeBook notebook.	Plugging in headphones disables the built-in speakers, remove the headphones.	
	BIOS audio settings are incorrect.	Set the BIOS setup utility to the default values within the Multimedia Device Configuration menu. (See BIOS Setup Utility on page 27 for more information)	
	Software driver is not configured correctly.	Refer to your application and operating system documentation for help.	
Media Player Drive Probl	ems		
LifeBook notebook fails to recognize media discs.	The disc is not pushed down onto raised center circle of the drive.	Open media player tray and re-install the media disc properly.	
	Media player tray is not latched shut.	Push on the front of the media player tray until it latches.	
	Setup utility is set to something other than media player or Auto for Secondary Master Controller.	Revise BIOS settings for the Secondary Master Controller. (See BIOS Setup Utility on page 27 for more information)	
	Wrong drive designator was used for media player in the application.	Verify the drive designator used by the application is the same as the one used by the operating system. When the operating system is booted from a media player, drive designators are automatically adjusted.	
	Windows Media Player auto insert notification function is disabled.	Start the media player from the desktop or application software or re-enable the Windows media player auto insert notification function. (See Auto Insert Notification Function on page 41 for more information)	
	Media disc is dirty or defective.	Wipe the disc with a non-abrasive CD cleaning cloth and reinsert. It if still will not work try another media disc in the drive.	

Problem	Possible Cause	Possible Solutions	
The Media Player Access indicator on the Status Indicator Panel blinks at regular intervals when no disc is in the tray or the media drive is not installed.	The Windows media player auto insert notification function is active and is checking to see if a media disc is ready to run.	This is normal. However, you may disable this feature. (See Auto Insert Notification Function on page 41 for more information)	
The media player will not play international DVD titles	The region code for the DVD does not match that of the media player.	All Fujitsu notebook DVD players are set to play DVD titles with region code number 1, which is specified for the North American market. The region number is a regional restriction code defined by the DVD Forum acting on the requirements of Hollywood. Different region codes are recorded on video DVD titles for publication in different areas of the world. If the regional code of the DVD player does not match the regional codes on the titles, then playback is impossible.	
		NOTE: You can change the region code on the DVD player using the Properties menu of the DVD software. Note, however, that you can only change the region code up to four times. After the fourth change, the last region code entered becomes permanent, and cannot be changed.	
The LifeBook notebook fails to Auto-Play a DVD movie.	The media player software has not been installed.	Locate and install the DVD-ROM Applications CD.	
Floppy Disk Drive Proble	ems		
You cannot access your floppy disk.	You tried to write to a write protected floppy disk.	Eject the floppy disk and set it to write enable. (See Internal Floppy Disk Drive on page 37 for more information)	
	Floppy disk is not loaded correctly.	Eject floppy disk, check orientation and re-insert. (See Internal Floppy Disk Drive on page 37 for more information)	
	BIOS setup utility states Floppy Disk Controller: Disabled.	Revise the setup utility Main menu settings to enable Diskette Controller. (See BIOS Setup Utility on page 27 for more information)	
	Security is set to protect access to floppy disk data.	Verify your password and security settings.	
Hard Drive Problems			
You cannot access your hard drive.	The setup utility is incorrectly set for your internal (Primary Master) or optional second hard drive (Primary Slave).	Revise BIOS settings to set both Primary Master and Primary Slave correctly. (See BIOS Setup Utility on page 27 for more information)	
	The wrong drive designator was used by an application when a bootable CD-ROM was used to start the LifeBook notebook.	Verify drive designator used by application is in use by the operating system. When the operating system is booted from a CD, drive designations are automatically adjusted.	

Problem	Possible Cause	Possible Solutions	
You cannot access your hard drive. (continued)	Security is set so your operating system cannot be started without a password.	Verify your password and security settings.	
Keyboard or Mouse Prob	lems		
The built-in keyboard does not seem to work.	The LifeBook notebook has gone into Suspend mode.	Push the Suspend/Resume button.	
	Your application has locked out your keyboard.	Try to use your intergrated pointing device to restart your system. If this fails, turn your LifeBook notebook off using the power switch, wait 10 seconds or more, and then turn it back on.	
You have installed an external keyboard or	Your external device is not properly installed.	Re-install your device. (See Device Ports on page 47 for more information)	
mouse, and it does not seem to work.	Your operating system software is not set up with the correct software driver for that device.	Check your device and operating system documentation and activate the proper driver.	
You have connected an external keyboard or a mouse and it seems to be	Your operating system software is not set up with the correct software driver for that device.	Check your device and operating system documentation and activate the proper driver.	
locking up the system.	Your system has crashed.	Try to restart your LifeBook notebook. If that fails, turn off the power using the power switch, wait at least 10 seconds, and then power on.	
Memory Problems			
Your Power On screen, or Main menu of the BIOS setup utility infor-	Your memory upgrade module is not properly installed.	Remove and re-install your memory upgrade module. (See Memory Upgrade Module on page 45 for more information)	
mation, does not show the correct amount of installed memory.	You have a memory failure.	Check for Power On Self Test (POST) messages. (See Power On Self Test Messages on page 80 for more information)	
Modem Problems			
Messages about modem operation.	Messages about modem operation are generated by whichever modem application is in use.	See your application software documentation for additional information.	
USB, Parallel, or IR Device	ce Problems		
You have installed a USB, parallel, or IR device. Your LifeBook	The device is not properly installed.	Remove and re-install the device. (See Device Ports on page 47 for more information)	
notebook does not recognize the device, or the device does not seem to work properly.	The device may have been installed while an application was running, so your LifeBook is not aware of its installation.	Close the application and restart your LifeBook notebook.	
	Your software may not have the correct software driver active.	See your software documentation and activate the correct driver.	

Problem	Possible Cause	Possible Solutions	
You have installed a USB, parallel, or IR device. Your LifeBook notebook does not	You may have the wrong I/O address selected for your device.	See your device documentation and software documentation to determine the required I/O address. Change the settings in the BIOS setup utility. (See figure on page 27 for location)	
recognize the device, or the device does not seem to work properly.	Your device and another device are assigned the same I/O address.	Check all I/O addresses located within the BIOS setup utility and any other installed hardware or software to make sure there are no duplications.	
	Parallel port is set to output only.	Check parallel port setting in the BIOS and set to bi-directional or ECP.	
PC Card Problems			
A card inserted in the PC Card slot does not	The card is not properly installed.	Remove and re-install the card. (See PC Cards on page 44 for more information)	
work or is locking up the system.	The card may have been installed while an application was running, so your LifeBook notebook is not aware of its installation.	Close the application and restart your LifeBook notebook.	
	Your software may not have the correct software driver active.	See your software documentation and activate the correct driver.	
	You may have the wrong I/O address selected for your PC Card device.	See your PC Card documentation to determine the required I/O address. Change the settings in the BIOS. (See BIOS Setup Utility on page 27 for more information)	
	Your PC Card device and another device are assigned the same I/O address.	Check all I/O addresses located within the BIOS setup utility and any other installed hardware or software to make sure there are no duplications.	
	The card may have been "removed" using the Unplug or Eject Hardware utility.	If the Unplug or Eject Hardware utility has been used to "remove" the PC card, the system will not recognize the card, even if it is still present in the slot. Physically remove the card and reinstall it in the slot. If that is not successful, reboot the system.	
Power Failures			
You turn on your LifeBook notebook and nothing seems to happen.	The installed primary battery is completely discharged, there is no optional second battery installed or there is no Power adapter (AC or Auto/Airline) installed.	Check the Status Indicator Panel to determine the presence and condition of the batteries. (See Status Indicator Panel on page 13 for more information) Install a charged battery or a Power adapter.	
	The primary battery is installed but is faulty.	Use the Status Indicator panel to verify the presence and condition of the batteries. (See Status Indicator Panel on page 13 for more information) If a battery is indicating a short, remove that battery and operate from another power source or replace that battery.	
	The battery or batteries are low.	Check the Status Indicator Panel to determine the presence and condition of the batteries. (See Status Indicator Panel on page 13 for more information) Use a Power adapter to operate until a battery is charged or install a charged battery.	

Problem	Possible Cause	Possible Solutions		
You turn on your LifeBook notebook and	The power adapter (AC or auto/airline) is not plugged in properly.	Verify that your adapter is connected correctly. (See Power Sources on page 25 for more information)		
nothing seems to happen. (continued)	The Power adapter (AC or auto/airline) has no power from the AC outlet, airplane seat jack, or the car's cigarette lighter.	Move the AC cord to a different outlet, check for a line switch or tripped circuit breaker for the AC outlet. If you are using an auto/airline adapter in a car make sure the ignition switch is in the On or Accessories position.		
	The Power adapter (AC or auto/airline) is faulty.	Try a different Power adapter or install a charged optional second battery.		
	Power switch is not in the On position.	Slide your power switch firmly to the Off position, pause 10 seconds or more and then slide it firmly to the On position.		
Your LifeBook notebook turns off all by itself.	The power management parameters are set for auto timeouts which are too short for your operating needs.	Press any button on the keyboard, or move the mouse to restore operation. If that fails, push the Suspend/Resume button. Check your power management settings, or close your applications and go to the Power Savings menu of the setup utility to adjust the timeout values to better suit your operation needs.		
	You are operating on battery power only and have ignored a low battery alarm until the batteries are all at the dead battery state and your machine has gone into Dead Battery Suspend mode.	Install a power adapter and then push the Suspend/ Resume button. (See Power Sources on page 25 for more information)		
	You have a battery failure.	Verify the condition of the batteries using the Status Indicator panel, and replace or remove any batteries that are shorted. (See Status Indicator Panel on page 13 for more information)		
	Your power adapter has failed or lost its power source.	Make sure the adapter is plugged in and the outlet has power.		
Your LifeBook note- book will not work on	The installed batteries are dead.	Replace the battery with a charged one or install a Power adapter.		
battery alone.	No batteries are installed.	Install a charged battery.		
	The batteries are improperly installed.	Verify that the batteries are properly connected by re-installing them.		
	Your installed batteries are faulty.	Verify the condition of the batteries using the Status Indicator panel and replace or remove any batteries that are shorted. (See Status Indicator Panel on page 13 for more information)		
The batteries seem to discharge too quickly.	You are running an application that uses a great deal of power due to frequent hard drive or media player drive access, use of a modem card or a LAN PC card.	Use both the primary battery and an optional second battery and/or use a power adapter for this application when at all possible.		

Problem	Possible Cause	Possible Solutions		
The batteries seem to discharge too quickly. (continued)	The power savings features may be disabled.	Check the power management and/or setup utility settings in the Power Savings menu and adjust according to your operating needs.		
	The brightness is turned all the way up.	Turn down the brightness adjustment. The higher the brightness the more power your display uses.		
	The batteries are very old.	Replace the batteries.		
	The batteries have been exposed to high temperatures.	Replace the batteries.		
	The batteries are too hot or too cold.	Restore the LifeBook to normal operating temperature. The Charging icon on the indicator panel will flash when the battery is outside operating range.		
Shutdown and Startup Pr	oblems			
The Suspend/Resume button does not work.	The Suspend/Resume button is disabled from the Advanced submenu of the Power menu of the setup utility.	Enable the button from the setup utility.		
	You did not hold the button in long enough.	Hold the button longer. This may need to be a few seconds if your application is preventing the CPU from checking for button pushes.		
There may be a conflict with the application software.		Close all applications and try the button again.		
The system powers up, and displays power on information, but fails to load the operating system.	The boot sequence settings of the setup utility are not compatible with your configuration.	Set the operating source by pressing the [ESC] key while the Fujitsu logo is on screen or use the [F2] key and enter the setup utility and adjust the source settings from the Boot menu. (See BIOS Setup Utility on page 27 for more information)		
	You have a secured system requiring a password to load your operating system.	Make sure you have the right password. Enter the setup utility and verify the Security settings and modify them as accordingly. (See BIOS Setup Utility on page 27 for more information)		
	Internal hard drive was not detected.	Use the BIOS setup utility or Primary Master submenu, located within the Main menu, to try to auto detect the internal hard drive.		
An error message is displayed during the LifeBook notebook (boot) sequence.	Power On Self Test (POST) has detected a problem.	See Power On Self Test (POST) messages to determine the meaning of the problem. Not all messages are errors; some are status indicators. (See Power Or Self Test Messages on page 80 for more information)		
Your LifeBook note- book appears to change setup parameters when you start it.	BIOS setup changes were not saved when you made them and exited the BIOS setup utility returning it to previous settings.	Make sure you select Save Changes And Exit when exiting the BIOS setup utility.		
	The BIOS CMOS hold-up battery has failed.	Contact your support representative for repairs. This is not a user serviceable part but has a normal life of 3 to 5 years.		

Problem	Possible Cause	Possible Solutions		
Video Problems	Video Problems			
Display is blank when you turn on the system.	Something is pushing on the Closed Cover switch.	Clear the Closed Cover switch. (See figure 2-3 on page 8 for location)		
	The LifeBook notebook is set for an external monitor only.	Pressing [F10] while holding down the [Fn] key allows you to change the destination of your display video. Each time you press the combination of keys you will step to the next choice. The choices, in order are: built-in display only, external monitor only, both built-in display and external monitor.		
	The angle and brightness settings of the display are not adequate for the lighting conditions.	Move the display and the brightness control until you have adequate visibility.		
	The power management timeouts may be set for very short intervals and you failed to notice the display come on and go off again.	Press any button the keyboard, or move the mouse to restore operation. If that fails, push the Suspend/ Resume button. (The display may be shut off by Standy mode, Auto Suspend or Video Timeout)		
When the ATI Driver CD is first installed, you receive a Microsoft message informing you that the ATI driver is not compatible with your operating system.	The warning does not apply to your LifeBook; the driver has been thoroughly tested and its installation will not jeopardize the performance of your system.	If this message appears on your screen, click the Continue Anyway or Yes buttons to proceed.		
The LifeBook notebook turned on with a series of beeps and your built- in display is blank.	Power On Self Test (POST) has detected a failure which does not allow the display to operate.	Contact your support representative.		
The display goes blank by itself after you have been using it.	The LifeBook notebook has gone into Video timeout, Standby mode, Suspend mode or Hibernation (Save-to-Disk) mode because you have not used it for a period of time.	Press any button on the keyboard, or move the mouse to restore operation. If that fails, push the Suspend/ Resume button. Check your power management settings, or close your applications and go to the Power Savings menu of the setup utility to adjust the timeout values to suit your operation needs. (See BIOS Setup Utility on page 27 for more information)		
	Something is pushing on the Closed Cover switch.	Check the Closed Cover switch. (See figure 2-3 on page 8 for location)		
	The power management timeouts may be set for very short intervals and you failed to notice the display come on and go off again.	Press any button on the keyboard, or move the mouse to restore operation. If that fails, push the Suspend/Resume button. (The display may be shut off by Standby Mode, Auto Suspend or Video Timeout)		
The Built-in Display does not close.	A foreign object, such as a paper clip, is stuck between the display and the keyboard.	Remove all foreign objects from the keyboard.		
The Built-in Display has bright or dark spots.	If the spots are very tiny and few in number, this is normal for a large LCD display.	This is normal; do nothing.		

Problem	Possible Cause	Possible Solutions	
The Built-in Display has bright or dark spots. (continued)	If the spots are numerous or large enough to interfere with your operation needs.	Display is faulty; contact your support representative.	
The application display uses only a portion of your screen and is surrounded by a dark frame.	You are running an application that does not support 800 x 600/1024 x 768 pixel resolution display and display compression is enabled.	Display compression gives a clearer but smaller display for applications that do not support 800 x 600 /1024 x 768 pixel resolution. You can fill the screen but have less resolution by changing your display compression setting, (See the Video Features submenu, located within the Advanced menu of the BIOS. (See BIOS Setup Utility on page 27 for more information)	
The Display is dark when on battery power.	The BatteryAid default is set on low brightness to conserve power.	Press [Fn] + [F7] to increase brightness or double- click on BatteryAid gauge and adjust Power Control under battery settings.	
You have connected an external monitor and it does not display any information.	Your BIOS setup is not set to enable your external monitor.	Toggle the video destination by pressing [Fn] and [F10] together, or check your BIOS setup and enable your external monitor. (See Video Features subment located within the Advanced Menu of the BIOS. (See BIOS Setup Utility on page 27 for more information)	
	Your external monitor is not properly installed.	Reinstall your device. (See External Monitor Port on page 48 for more information)	
	Your operating system software is not setup with the correct software driver for that device.	Check your device and operating system documentation and activate the proper driver.	
You have connected an external monitor and it does not come on.	Your external monitor is not compatible with your LifeBook notebook.	See your monitor documentation and the External Monitor Support portions of the Specifications section.	
The Properties section of the Intel Graphics Tech- nology window displays an incorrect amount of Video RAM present.	This is not a problem; it is a result of UMA technology.	The Intel graphics chipset uses Unified Memory Architecture (UMA) which allows the video chipse to share up to 48MB of the system's main memory. The amount being used will vary with the system needs, and the amount of video RAM indicated will vary as well.	
Miscellaneous Problems			
An error message is displayed on the screen during the operation of an application.	Application software often has its own set of error message displays.	See your application manual and help displays screens for more information. Not all messages are errors some may simply be status.	

POWER ON SELF TEST MESSAGES

The following is an alphabetic list of error-and-status messages that Phoenix BIOS and/or your operating system can generate and an explanation of each message. Error messages are marked with an *. The most common errors are marked with a #. If an error message is displayed that is not in this list, write it down and check your operating system documentation both on screen and in the manual. If you can find no reference to the message and its meaning is not clear, contact your support representative for assistance.

nnnn Cache SRAM Passed

Where nnnn is the amount of system cache in kilobytes success-fully tested by the Power On Self Test. (This can only appear if you have an SRAM PC Card installed.)

*Diskette drive A error or Diskette drive B error

Drive A: or B: is present but fails the BIOS Power On Self Test diskette tests. Check to see that the drive is defined with the proper diskette type in the Setup Utility, (See BIOS Setup Utility on page 27 for more information) and that the diskette drive is installed correctly. If the disk drive is properly defined and installed, avoid using it and contact your support representative.

*Extended RAM Failed at offset: nnnn

Extended memory not working or not configured properly. If you have an installed memory upgrade module, verify that the module is properly installed. If it is properly installed, you may want to check your Windows Setup to be sure it is not using unavailable memory until you can contact your support representative.

nnnn Extended RAM Passed

Where nnnn is the amount of memory in kilobytes successfully tested.

*Failing Bits: nnnn The hex number nnnn

This is a map of the bits at the memory address (in System, Extended, or Shadow memory) which failed the memory test. Each 1 (one) in the map indicates a failed bit. This is a serious fault that may cause you to lose data if you continue. Contact your support representative.

*Fixed Disk x Failure or Fixed Disk Controller Failure (where x = 1-4)

The fixed disk is not working or not configured properly. This may mean that the hard drive type identified in your setup utility does not agree with the type detected by the Power On Self Test. Run the setup utility to check for the hard drive type settings and correct them if necessary. If the settings are OK and the message appears when you restart the system, there may be a serious fault which might cause you to lose data if you continue. Contact your support representative.

*Incorrect Drive A type - run SETUP

Type of floppy drive A: not correctly identified in Setup. This means that the floppy disk drive type identified in your setup utility does not agree with the type detected by the Power On Self Test. Run the setup utility to correct the inconsistency.

*Incorrect Drive B type - run SETUP

Type of floppy drive B: not correctly identified in Setup. This means that the floppy disk drive type identified in your setup utility does not agree with the type detected by the Power On Self Test. Run the setup utility to correct the inconsistency.

*Invalid NVRAM media type

Problem with NVRAM access. In the unlikely case that you see this message you may have some display problems. You can continue operating but should contact your support representative for more information.

*Keyboard controller error

The keyboard controller test failed. You may have to replace your keyboard or keyboard controller but may be able to use an external keyboard until then. Contact your support representative.

*Keyboard error

Keyboard not working. You may have to replace your keyboard or keyboard controller but may be able to use an external keyboard until then. Contact your support representative.

*Keyboard error nn

BIOS discovered a stuck key and displays the scan code for the stuck key. You may have to replace your keyboard but may be able to use an external keyboard until then. Contact your support representative.

*Monitor type does not match CMOS - Run SETUP

Monitor type not correctly identified in Setup. This error probably means your BIOS is corrupted, run the setup utility and set all settings to the default conditions. If you still get this error, contact your support representative.

#*Operating system not found

Operating system cannot be located on either drive A: or drive C: Enter the setup utility and see if both the fixed disk, and drive A: are properly identified and that the boot sequence is set correctly. Unless you have changed your installation greatly, the operating system should be on drive C:. If the setup utility is correctly set, your hard drive may be corrupted and your system may have to be re-installed from your back up media.

*Parity Check 1 nnnn

Parity error found in the system bus. BIOS attempts to locate the address and display it on the screen. If it

cannot locate the address, it displays ????. This is a potentially data destroying failure. Contact your support representative.

*Parity Check 2 nnnn

Parity error found in the I/O bus. BIOS attempts to locate the address and display it on the screen. If it cannot locate the address, it displays ????. This is a potentially data destroying failure. Contact your support representative.

#*Press <F1> to resume, <F2> to SETUP

Displayed after any recoverable error message. Press the [F1] key to continue the boot process or the [F2] key to enter Setup and change any settings.

#*Previous boot incomplete – Default configuration used

Previous Power On Self Test did not complete successfully. The Power On Self Test will load default values and offer to run Setup. If the previous failure was caused by incorrect values and they are not corrected, the next boot will likely fail also. If using the default settings does not allow you to complete a successful boot sequence, you should turn off the power with the Power Switch and contact your support representative.

*Real time clock error

Real-time clock fails BIOS test. May require board repair. Contact your support representative.

*Shadow RAM Failed at offset: nnnn

Shadow RAM failed at offset nnnn of the 64k block at which the error was detected. You are risking data corruption if you continue. Contact your support representative.

nnnn Shadow RAM Passed

Where nnnn is the amount of shadow RAM in kilobytes successfully tested.

*System battery is dead - Replace and run SETUP

The BIOS CMOS RAM memory hold up battery is dead. This is part of your BIOS and is a board mounted battery which requires a support representative to change. You can continue operating but you will have to use setup utility default values or reconfigure your setup utility every time you turn off your LifeBook notebook. This battery has an expected life of 2 to 3 years.

System BIOS shadowed

System BIOS copied to shadow RAM.

*System CMOS checksum bad - run SETUP

BIOS CMOS RAM has been corrupted or modified incorrectly, perhaps by an application program that changes data stored in BIOS memory. Run Setup and reconfigure the system.

*System RAM Failed at offset: nnnn

System memory failed at offset nnnn of in the 64k block at which the error was detected. This means that there is a fault in your built-in memory. If you continue to operate, you risk corrupting your data. Contact your support representative for repairs.

nnnn System RAM Passed

Where nnnn is the amount of system memory in kilobytes successfully tested.

*System timer error

The timer test failed. The main clock that operates the computer is faulty. Requires repair of system board. Contact your support representative for repairs.

UMB upper limit segment address: nnnn

Displays the address of the upper limit of Upper Memory Blocks, indicating released segments of the BIOS memory which may be reclaimed by a virtual memory manager.

Video BIOS shadowed

Video BIOS successfully copied to shadow RAM.

EMERGENCY MEDIA PLAYER TRAY RELEASE

If for some reason the eject button fails, you can open the media player tray with a paper clip or similar tool inserted into the eject hole in the far right side of the front of the tray. Straighten one side of a paper clip and push it gently into the hole. The tray will pop out.

MODEM RESULT CODES

The operating system and application software that is factory installed detects the modem characteristics and provides the necessary command strings to operate the modem. The internal modem operation is controlled by generic AT commands from the operating system and application software. The standard long form result codes may, in some cases, be displayed on your screen to keep you informed of the actions of your modem. The operating system and application software may suppress display of the result codes.

Examples of result codes are:

- OK
- NO CARRIER
- NO DIALTONE
- CONNECT 53000 (Connection complete at 53kbps.)
- ERROR
- FAX
- RING (This means an incoming call.)
- BUSY
- NO ANSWER

When using the internal modem with applications that are not factory installed refer to the application documentation.

DRIVERS AND APPLICATIONS CD

The Drivers and Applications CD contains:

- Sets of device drivers and Fujitsu utilities (in specific directories) that are unique to your LifeBook notebook configuration for use as documented below.
- Read-me files that provide additional use information for items on this CD-ROM.



POINT

If you have access to the internet, visit the Fujitsu Support web site at www.fujitsupc.com to check for the most current information, drivers and hints on how to perform recovery and system updates.

DRIVE IMAGE SPECIAL EDITION (DISE)

PowerQuest Drive Image Special Edition (DISE) provides a way to restore your computer if you experience a hard disk crash or other system failure. Fujitsu has used DISE to create an image of everything installed on the computer at the time you purchased it. The image is saved on a separate partition on the hard disk. You can use DISE to restore the factory image and return your computer to the state in which it shipped from Fujitsu.

Although it is not necessary, you can use DISE to store additional image files that you create. For example, if you install several applications and save data files on your hard disk, you can create a new image file that includes them and then save that image file on the hard disk. Then, in the event of a hard disk failure, you can restore the image that includes the applications and data files you use.

Fujitsu recommends that you create a DISE boot diskette as a "rescue disk." If your computer fails, you can boot and run DISE from the rescue disk.



POINT

Using the DISE feature will reduce the amount of usable disk space on your hard disk drive.

Creating a Drive Image SE Diskette

You can use a DISE disk to boot your machine and run DISE if your machine is unbootable or if you do not have access to Windows.

Insert a formatted floppy disk in your machine.

From the Drive Image Special Edition main window, click Options > Create Drive Image SE Diskette.

Running DISE from Diskettes

- 1. Insert the Drive Image SE Disk 1 in the floppy drive.
- 2. Reboot your computer.
- 3. Insert Disk 2, type DISE, then press <Enter>.

Creating a Backup Image

You can create a backup image of your C:\ drive at any time. The C:\ partition must be a FAT, FAT32, or NTFS partition, and it must be directly before the backup partition on your hard disk.

- At the Drive Image Special Edition main screen, click Options > Create New Backup.
 There is also a button on the main DISE screen that performs the same function.
- You will be prompted to type a password. Type a password (or leave the password fields blank), then click OK. DISE displays a warning that it must go to DOS to create the image.
- Click Yes.

DISE creates an image file in the backup partition. If you created a backup image previously, the new image overwrites the old one.

Enlarging the Backup Partition

If there is not enough unused space in the backup partition on your hard disk, DISE will resize the partition. DISE will display the minimum, maximum, and recommended sizes for the backup partition. You choose the size you want.

DISE takes the space from the FAT, FAT32, or NTFS partition that you are backing up. If there is not enough unused space in that partition to take, you will not be able to resize the backup partition and create an image file. You can delete files from the FAT, FAT32, or NTFS partition to create more unused space on the hard disk.

Restoring a Backup Image

You can restore either a factory image or a backup image you created. Be aware that restoring a backup image will replace the contents of the C:\ partition with the image you restore.

- Disable virus protection software. If virus protection software is enabled, DISE will hang.
- From the DISE main window, click Options >
 Restore Backup to restore an image you created, or
 click Options > Restore Factory Backup to restore
 the factory image.

DISE shuts down to DOS and restores the image file.

Drivers and Applications Restore CD

The Drivers and Application CD can be used to selectively re-install drivers and/or applications that may have been un-installed or corrupted. Please refer to installation instructions located in the Drivers and Applications Restore CD.



POINT

Look for and open files with the extensions .DOC, .PDF and/or .TXT.

7 Care and Maintenance

LifeBook C Series Notebook - Section Seven

Care and Maintenance

If you use your LifeBook notebook carefully, you will increase its life and reliability. This section provides some tips for looking after the LifeBook notebook and its devices.

AWARNING

Electrical equipment may be hazardous if misused. Operations of this product or similar products must always be supervised by an adult. Do not allow children access to the interior of any electrical products and do not permit them to handle any cables.

LIFEBOOK NOTEBOOK

Caring for your LifeBook notebook

- Your LifeBook notebook is a durable but sensitive electronic device. Treat it with respect and care.
- Make a habit of transporting it in a suitable carrying case.
- Do not attempt to service the computer yourself.
 Always follow installation instructions closely.
- Keep it away from food and beverages.
- If you accidentally spill liquid on your LifeBook notebook:
 - 1. Turn it off.
 - 2. Position it so that the liquid can run out.
 - 3. Let it dry out for 24 hours, or longer if needed.
 - 4. If your LifeBook notebook will not boot after it has dried out, call your support representative.
- Do not use your LifeBook notebook in a wet environment (near a bathtub, swimming pool).
- Always use the AC adapter and batteries that are approved for your LifeBook notebook.
- Avoid exposure to sand, dust and other environmental hazards.
- Do not expose your LifeBook notebook to direct sunlight for long periods of time as temperatures above 140° F (60° C) may damage your notebook.
- Keep the covers closed on the connectors and slots when they are not in use.
- Do not put heavy or sharp objects on the computer.
- If you are carrying your LifeBook notebook in a briefcase, or any other carrying case, make sure that there are no objects in the case pressing on the lid.
- Never position your LifeBook notebook such that the media player drive is supporting the weight of the notebook.
- Do not drop your LifeBook notebook.

• Do not touch the screen with any sharp objects.

Cleaning your Fujitsu notebook

- Always disconnect the power plug. (Pull the plug, not the cord.)
- Clean your LifeBook notebook with a damp, lint-free cloth. Do not use abrasives or solvents.
- Use a soft cloth to remove dust from the screen.
 Never use glass cleaners.

Storing your Fujitsu notebook

- If storing your LifeBook notebook for a month or longer, turn your LifeBook notebook off, fully charge the battery, the remove and store all Lithium ion batteries.
- Store your LifeBook notebook and batteries separately. If you store your LifeBook notebook with a battery installed, the battery will discharge, and battery life will be reduced. In addition, a faulty battery might damage your LifeBook notebook.
- Store your LifeBook notebook in a cool, dry location.
 Temperatures should remain between 13°F (-25°C) and 140°F (60°C).

Traveling with your Fujitsu notebook

- Do not transport your LifeBook notebook while it is turned on.
- Do not check your LifeBook notebook as baggage.
 Carry it with you.
- Always bring your System Recovery CD that came with your LifeBook notebook when you travel. If you experience system software problems while traveling, you may need it to correct any problems.
- Avoid putting your LifeBook notebook through a metal detector. Have your notebook hand-inspected by security personnel. You can however, put your LifeBook notebook through a properly tuned X-ray machine. To avoid problems, place your notebook close to the entrance of the machine and remove it as soon as possible or have your LifeBook notebook hand-inspected by security personnel. Security officials may require you to turn your LifeBook notebook On. Make sure you have a charged battery on hand.
- When traveling with the hard drive removed, wrap the drive in a non-conducting materials (cloth or paper). If you have the drive checked by hand, be ready to install the drive if needed. Never put your hard drive through a metal detector. Have your hard drive hand-inspected by security personnel. You can however, put your hard drive through a properly tuned X-ray machine.
- Take the necessary plug adapters if you're traveling overseas. Check the following diagram to determine which plug adapter you'll need or ask your travel agent.

Outlet Type	Location		
	United States, Canada, parts of Latin America, Japan, Korea, Mexico, the Philippines, Taiwan		
••	Russia and the Commonwealth of Independent States (CIS), most of Europe, parts of Latin America, the Middle East, parts of Africa, Hong Kong, India, most of South Asia		
1	United Kingdom, Ireland, Malaysia, Singapore, parts of Africa		
	China, Australia, New Zealand		

BATTERIES

Caring for your Batteries

- Always handle batteries carefully.
- Do not short-circuit the battery terminals (that is, do not touch both terminals with a metal object). Do not carry lose batteries in a pocket or purse where they may mix with coins, keys, or other metal objects.
 Doing so may cause an explosion or fire.
- Do not drop, puncture, disassemble, mutilate or incinerate the battery.
- Recharge batteries only as described in this manual and only in ventilated areas.
- Do not leave batteries in hot locations for more than a day or two. Intense heat can shorten battery life.
- Do not leave a battery in storage for longer than 6 months without recharging it.

Increasing Battery Life

- Power your LifeBook notebook through the AC or optional auto/airline adapter whenever possible.
- If your LifeBook notebook is running on battery power all day, connect it to the AC adapter overnight to recharge the battery.
- Keep brightness to the lowest level comfortable.
- Set the power management for maximum battery life.
- Put your LifeBook notebook in Suspend mode when it is turned on and you are not actually using it.

- Limit your media drive access.
- Disable the media player auto insert notification function.
- Always use fully charged batteries.
- Eject PCMCIA[™] cards when not in use.

FLOPPY DISKS AND DRIVES Caring for your Floppy Disks

- Avoid using the floppy disks in damp and dusty locations.
- Never store a floppy disk near a magnet or magnetic field.
- Do not use a pencil or an eraser on a disk or disk label.
- Avoid storing the floppy disks in extremely hot or cold locations, or in locations subject to severe temperature changes. Store at temperatures between 50° F (10°C) and 125°F (52°C).
- Do not touch the exposed part of the disk behind the metal shutter.

Caring for your Floppy Disk Drive

- To clean, wipe the floppy disk drive clean with a dry soft cloth, or with a soft cloth dampened with water or a solution of neutral detergent. Never use benzene, paint thinner or other volatile material.
- Avoid storing the floppy disk drive in extremely hot or cold locations, or in locations subject to severe temperature changes. Store at temperatures between 50° F (10°C) and 125°F (52°C).
- Keep the floppy disk drive out of direct sunlight and away from heating equipment.
- Avoid storing the floppy disk drive in locations subject to shock and vibration.
- Never use the floppy disk drive with any liquid, metal, or other foreign matter inside the floppy disk drive or disk.
- Never disassemble or dismantle your floppy disk drive.

MEDIA CARE

Caring for your Media (DVD/CD/CD-R/DVD-R/DVD-RW)

Media discs are precision devices and will function reliably if given reasonable care.

- Always store your media disc in its case when it is not in use.
- Always handle discs by the edges and avoid touching the surface.
- Avoid storing any media discs in extreme temperatures.
- Do not bend media discs or set heavy objects on them.
- Do not spill liquids on media discs.
- Do not scratch media discs.
- Do not put a label on media discs.
- Do not get dust on media discs.
- Never write on the label surface with a ballpoint pen or pencil. Always use a felt pen.
- If a media disc is subjected to a sudden change in temperature, cold to warm condensation may form on the surface. Wipe the moisture off with a clean, soft, lint free cloth and let it dry at room temperature. DO NOT use a hair dryer or heater to dry media discs.
- If a disc is dirty, use only a DVD/CD cleaner or wipe it with a clean, soft, lint free cloth starting from the inner edge and wiping to the outer edge.

Caring for your Media Player Drive

Your media player drive is durable but you must treat it with care. Please pay attention to the following points:

- The drive rotates the compact disc at a very high speed. Do not carry it around or subject it to shock or vibration with the power on.
- Avoid using or storing the drive where it will be exposed to extreme temperatures.
- Avoid using or storing the drive where it is damp or dusty.
- Avoid using or storing the drive near magnets or devices that generate strong magnetic fields.
- Avoid using or storing the drive where it will be subjected to shock or vibration.
- Do not disassemble or dismantle the media player drive.

PC CARDS

Caring for your PC Cards

PC Cards are durable, but you must treat them with care. The documentation supplied with your PC Card will provide specific information, but you should pay attention to the following points:

- To keep out dust and dirt, store PC Cards in their protective sleeves when they are not installed in your LifeBook notebook.
- Avoid prolonged exposure to direct sunlight or excessive heat.
- Keep the cards dry.
- Do not flex or bend the cards, and do not place heavy objects on top of them.
- Do not force cards into the slot.
- Avoid dropping cards, or subjecting them to excessive vibration.

LifeBook C Series Notebook - Section Seven

8 Specifications

LifeBook C Series Notebook - Section Eight

Specifications

This section provides the hardware, software, and environmental specifications for your LifeBook notebook. Specifications of particular configurations will vary.

CONFIGURATION LABEL

Your LifeBook notebook contains a configuration label located on the bottom of your LifeBook notebook. (See figure 2-7 on page 12 for location) This label contains specific information regarding the options you've chosen for your LifeBook notebook. Following is an example label and information on how to read your own configuration label.




Figure 8-1 Configuration Label

MICROPROCESSOR

- Intel Pentium 4 processor*
- 512KB on-die L2 cache.
 - * An "M" suffix in the Processor section of the configuration label (above) indicates that the system has a mobile processor with Intel SpeedStep Technology. You can determine the speed of your processor by referring to the configuration label.

MEMORY

System Memory

256MB on-board, with one open DIMM slot for expansion up to 768MB SDRAM, PC2100 (DDR, 266MHz) via DIMM modules. (Reference the table on page 46 for a list of memory configurations.)

BIOS Memory

1024KB Flash ROM. 256 Bytes CMOS RAM

VIDEO

Built-in color flat-panel TFT active matrix LCD display with simultaneous display capability.

Video Color and Resolution

15" XGA TFT and 14.1" XGA TFT

- Internal: 1024 x 768 pixel resolution, 16M colors.
- External: 1600 x 1200 (max) pixel resolution, 16M colors.
- Simultaneous Video: 1024 x 768 pixel resolution

Video RAM

ATI® MOBILITY RADEON IGP340 integrated graphics chipset. The video memory is shared with system

memory and is user-selectable (16MB/32MB/64MB, with 32MB the default).

AUDIO

- SigmaTel STAC9767, 18-bit stereo audio 3D-Stereo supported
- Stereo headphone jack, 1 Vrms, or less, minimum impedance 32 Ohms
- Stereo line in jack, 880 mVrms or less, minimum impedance 10K Ohms
- Mono microphone jack, 125 mVp-p or less, minimum impedance 10K Ohms
- Two built-in speakers, 28 mm diameter, stereo, boxless
- SPDIF port for AC-3 digital audio out, shared with line-in.

MASS STORAGE DEVICE OPTIONS

Floppy Disk Drive

Internal 3. 5" Floppy Disk Drive, which accommodates 1.44MB or 720KB floppy disks.

Hard Drive

30GB, 40GB, or 60GB fixed hard drive, Ultra DMA 100

Media Player Drive

(One of the following devices, depending upon the configuration of your system).

- DVD-RW Drive:
 1x (DVD-R) / 1x (DVD-RW) / 8x (DVD-ROM) / 16x
 (CD-R) / 10x (CD-RW) / 24x (CD-ROM)
- DVD/CD-RW Combo Drive:
 16x (CD-R) / 10x (CD-RW) / 24x (CD) / plus 8x DVD
- DVD Drive: 8x max
- CD-ROM Drive: 24x max

INTEGRATED POINTING DEVICE

Touch pad pointing device with scrolling button.

COMMUNICATIONS

- Modem: Internal multinational V.90 standard 56K* fax/modem (ITU V.90, 56K data, 14.4K fax.)
- LAN: 10/100 Base-Tx Ethernet
- Optional Wireless LAN (802.11b), Wi-Fi-compliant (Note that the wireless LAN is an option only with the 15" model)
 - * Actual speeds over U.S. telephone lines vary and are less than 56Kbps due to the current FCC regulations and line conditions. The internal modems on all Life-Book notebooks are only qualified for use with telephone systems inside the United States and Canada and may not operate in other countries.

LIFEBOOK APPLICATION PANEL

Application Launcher and Audio CD Player. The Application Launcher is pre-set with the following defaults assigned to each button:

Application A: Notepad

Application B: Fujitsu Service Assistant

Internet: Internet Explorer or default browser

E-Mail: Netscape Messenger

THEFT PREVENTION LOCK SLOT

Lock slot for use with physical restraining security systems. The Kensington lock system is recommended.

DEVICE PORTS

- Combination PC Card slot for one Type III/two Type II cards: PCMCIA Standard 2.1 with CardBus support
- One media slot for a Memory Stick or Secure Digital (SD) card
- One 15-pin D-SUB connector for VGA external monitor (see Video specifications).
- Four connectors for USB 2.0 (Universal Serial Bus) input/output devices.
- One modular modem (RJ-11) connector.
- One modular Ethernet (RJ-45) jack
- One IEEE 1394 jack (4-pin type)
- Fast IR (up to 4 Mbps) compatible infrared port for wireless data transfer
- One 25-pin D-SUB connector for parallel input/ output devices (bi-directional output only for ECP)
- One mono microphone jack. (See Audio specifications)
- One Optical Digital Audio-Out/Headphone jack. (See Audio specifications)
- One S-Video out port

KEYBOARD

Built-in keyboard with all functions of 101 key PS/2 compatible keyboards.

- Total number of keys: 87
- Function keys: 12, F1 through F12
- Feature extension key: Fn
- Three Windows keys: two Start keys and one application key
- Key pitch: 19 mm
- Key stroke: 3 mm
- Built-in touchpad with scroll button
- Built-in Palm Rest

External Keyboard Support

USB-compatible

External Numeric Keypad Support

USB-compatible

External Mouse Support

USB-compatible

POWER

Batteries

One 8-cell Lithium ion Battery, rechargeable, 14.4V, 3600 mAh

AC Adapter

Autosensing 100-240V AC, 80W, supplying 19V DC, 4.22A to the LifeBook notebook, Fujitsu Model FPCAC33 which includes an AC cable.

Power Management

Conforms to ACPI (Advanced Configuration and Power Interface).

Electrostatic Discharge (ESD): 9 kV

DIMENSIONS AND WEIGHT

Overall Dimensions

12.8" (w) x 11.1" (d) x 1.5/2.3" (h) (325.3 x 282 x 39.11/59.3 mm)

Weight

15" Display model:

Approximately 8.3 lbs. (3.78 kg) with battery and DVD-RW drive

14.1" Display model:

Approximately 8.27 lbs. (3.75 kg) with battery and DVD-RW drive

ENVIRONMENTAL REQUIREMENTS

Temperature

Operating: 5° to 35° C (41° to 95° F). Non-operating: –15° to 60° C (5° to 140° F).

Humidity

Operating: 20% to 85%, relative, non-condensing. Non-operating: 8% to 85%, relative, non-condensing.

Altitude

Operating: 10,000 feet (3,048 m) maximum

PRE-INSTALLED SOFTWARE

Your LifeBook Series notebook comes with pre-installed software for playing audio and video files of various formats. In addition there is file transfer software, virus protection software, and Power Management software.

Table 8-1 Pre-Installed Software

Software	Operating System Applicability		
	Windows 2000 Professional	Windows XP Professional	Windows XP Home
Microsoft Works		X	X
Adobe Acrobat Reader	Х	Х	Х
BatteryAid	Х		
Fujitsu HotKey		Х	Х
Drive Image Special Edition (DISE)	Х	X	Х
EarthLink 5.0	Х	Х	Х
Fujitsu Service Assistant	Х	Х	Х
LifeBook Application Panel	Х	Х	Х
McAfee.com VirusScan Online	Х	Х	Х
Netscape 6	Х	Х	Х
Quicken New User Edition		Х	Х

Tutorials

All operating systems and most application software have tutorials built-into them upon installation. We highly recommend that you step through the tutorial before you use an application.

Manuals

Included with your notebook you will find manuals for your installed operating system and other pre-installed software. Any manuals that are not included, are available online through the help system of the software. We recommend that you review these manuals for general information on the use of these applications.

Microsoft Windows

Depending upon the configuration of your system, Microsoft Windows XP Home, Windows XP Professional, or Windows 2000 Professional is installed as your operating system.

Adobe Acrobat Reader by Adobe Systems, Inc.

The Adobe Acrobat Reader allows you to view, navigate, and print PDF files from across all of the major computing platforms.

Drive Image Special Edition (DISE) by PowerQuest

DISE provides a way to restore your computer if you experience a hard disk crash or other system failure. DISE is used to restore the factory image and restore the system to its original state.

McAfee.com Scan for Virus

Scan for Virus, by McAfee.com, is a web-based antivirus program that can be run from the McAfee.com website after loading data or programs onto your LifeBook notebook. It assists in the protection of the data currently residing on your hard disk from destruction or contamination. Your system comes with a free 30-day trial edition for unlimited updates of the virus data file during that period. We encourage you to subscribe with McAfee.com to continue receiving updates for protection from computer virus infections. (For more information on McAfee.com Scan for Virus, visit their Web site at www.mcafee.com.)

McAfee.com Personal Firewall

McAfee.com Personal Firewall provides privacy protection and a two-way defense against unauthorized Internet connections. Personal Firewall can be found on your Driver and Application Restore CD. (For more information on McAfee.com Personal Firewall, go to www.mcafee.com.)

LifeBook Application Panel Software

Your notebook is pre-installed with software utilities that let you operate and configure your LifeBook Application Panel. These utilities are found under the Start menu, under Programs, then under LifeBook Application Panel.

Netscape 6

Browser suite, including integrated E-mail accounts, instant messaging, address book, search, and other tools and plug-ins.

■ Microsoft Internet Explorer

Internet Explorer is installed as your default internet browser.

■ Earthlink 5.0

Software suite that allows you to connect with the Internet.

Microsoft Works 7.0 (Windows XP models only)

Microsoft Works 7.0 is a suite of software containing the basic tools to write letters and reports, track family and friends with address books, manage home finances, and create a home inventory.

Quicken 2003 New User Edition (Windows XP models only)

Quicken 2003 New User Edition by Intuit is a personal money management program. It has features such as portfolio management, account registries, on-line banking and bill paying features. This application is for new users who are using Quicken software for the first time. Full version upgrade information is available on line.

BatteryAid (Windows 2000 only)

BatteryAid allows you to control the display brightness of your notebook in order to maximize battery life. (See your BatteryAid online help for more information on the correct way to use this program)

■ Fujitsu HotKey (Windows XP only)

Fujitsu HotKey allows you to control the display brightness of your notebook in order to maximize battery life.

Regulatory Information

NOTICE

Changes or modifications not expressly approved by Fujitsu could void this user's authority to operate the equipment.

FCC NOTICES

Notice to Users of Radios and Television

These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet that is on a different circuit than the receiver.
- Consult the dealer or an experienced radio/TV technician for help.

Shielded interconnect cables must be employed with this equipment to ensure compliance with the pertinent RF emission limits governing this device.

Notice to Users of the US Telephone Network

This equipment complies with Part 68 of the FCC rules, and the requirements adopted by ACTA. On the bottom of this equipment is a label that contains, among other information, the FCC registration number and ringer equivalence number (REN) for this equipment; or a product identifier in the format US:AAAEQ##TXXXX. If requested, this information or number must be provided to the telephone company.

This equipment is designed to be connected to the telephone network or premises wiring using a standard jack type USOC RJ11C. A plug and jack used to connect this equipment to the premises wiring and telephone network must comply with the applicable FCC Part 68 rules and requirements adopted by the ACTA. A compliant telephone cord and modular plug is provided with this product. It is designed to be connected to a compatible modular jack that is also compliant.

The ringer equivalent number (REN) of this equipment is 0.0B. The REN is used to determine the number of devices that may be connected to a telephone line. Excessive RENs on a telephone may result in the devices not

ringing in response to an incoming call. In most but not all areas, the sum of RENs should not exceed five (5.0). To be certain of the number of devices that may be connected to a line, as determined by the total RENs, contact the local telephone company. For products approved after July 23, 2001, the REN for this product is part of the product identifier that has the format US:AAAEQ##TXXXX. The digits represented by ## are the REN without a decimal point (e.g., 00 is a REN of 0.0). For earlier products, the REN is separately shown on the label.

If this equipment causes harm to the telephone network, the telephone company will notify you in advance that temporary discontinuance of service may be required. But if advance notice isn't practical, the telephone company will notify the customer as soon as possible. Also, you will be advised of your right to file a complaint with the FCC if you believe it is necessary.

The telephone company may make changes in its facilities, equipment, operations or procedures that could affect the operation of the equipment. If this happens, the telephone company will provide advance notice in order for you to make necessary modifications to maintain uninterrupted service.

If trouble is experienced with this equipment, for repair or warranty information, please refer to the manual or contact Fujitsu PC Corporation, Customer Service. If the equipment is causing harm to the telephone network, the telephone company may request that you disconnect the equipment until the problem is resolved.

The equipment cannot be used on public coin service provided by the telephone company. Connection to party line service is subject to state tariffs. (Contact the state public utility commission, public service commission or corporation commission for information).

If your home has specially wired alarm equipment connected to the telephone line, ensure the installation of this computer does not disable your alarm equipment. If you have any questions about what will disable alarm equipment, consult your telephone company or a qualified installer.

The Telephone Consumer Protection Act of 1991 makes it unlawful for any person to use a computer or other electronic device to send any message via a telephone fax machine unless such message clearly contains in a margin at the top or bottom of each transmitted page or on the first page of the transmission, the date and time it is sent, and an identification of the business or other entity, or other individual sending the message and the telephone number of the sending machine or such business, other entity, or individual.

DOC (INDUSTRY CANADA) NOTICES Notice to Users of Radios and Television

This Class B digital apparatus meets all requirements of Canadian Interference-Causing Equipment Regulations.

CET appareil numérique de la class B respecte toutes les exigence du Réglement sur le matérial brouilleur du Canada.

Notice to Users of the Canadian Telephone Network

NOTICE: This equipment meets the applicable Industry Canada Terminal Equipment Technical Specifications. This is confirmed by the registration number. The abbreviation, IC, before the registration number signifies that registration was performed based on a Declaration of Conformity indicating that Industry Canada technical specifications were met. It does not imply that Industry Canada approved the equipment.

Before connecting this equipment to a telephone line the user should ensure that it is permissible to connect this equipment to the local telecommunication facilities. The user should be aware that compliance with the certification standards does not prevent service degradation in some situations.

Repairs to telecommunication equipment should be made by a Canadian authorized maintenance facility. Any repairs or alterations not expressly approved by Fujitsu or any equipment failures may give the telecommunication company cause to request the user to disconnect the equipment from the telephone line.

NOTICE: The Ringer Equivalence Number (REN) for this terminal equipment is 0.0. The REN assigned to each terminal equipment provides an indication of the maximum number of terminals allowed to be connected to a telephone interface. The termination on an interface may consist of any combination of devices subject only to the requirement that the sum of the Ringer Equivalence Numbers of all the devices does not exceed five.

CAUTION

For safety, users should ensure that the electrical ground of the power utility, the telephone lines and the metallic water pipes are connected together. Users should NOT attempt to make such connections themselves but should contact the appropriate electric inspection authority or electrician. This may be particularly important in rural areas.

Avis Aux Utilisateurs Du Réseau Téléphonique Canadien

AVIS: Le présent matériel est conforme aux spécifications techniques d'Industrie Canada applicables au matériel terminal. Cette conformité est confirmée par le numéro d'enregistrement. Le sigle IC, placé devant le

numéro d'enregistrement, signifie que l'enregistrement s'est effectué conformément à une déclaration de conformité et indique que les spécifications techniques d'Industrie Canada ont été respectées. Il n'implique pas qu'Industrie Canada a approuvé le matériel.

Avant de connecter cet équipement à une ligne téléphonique, l'utilisateur doit vérifier s'il est permis de connecter cet équipement aux installations de télécommunications locales. L'utilisateur est averti que même la conformité aux normes de certification ne peut dans certains cas empêcher la dégradation du service.

Les réparations de l'équipement de télécommunications doivent être eVectuées par un service de maintenance agréé au Canada. Toute réparation ou modification, qui n'est pas expressément approuvée par Fujitsu, ou toute défaillance de l'équipement peut entraîner la compagnie de télécommunications à exiger que l'utilisateur déconnecte l'équipement de la ligne téléphonique.

AVIS: L'indice d'équivalence de la sonnerie (IES) du présent matériel est de 0.0. L'IES assigné à chaque dispositif terminal indique le nombre maximal de terminaux qui peuvent être raccordés à une interface téléphonique. La terminaison d'une interface peut consister en une combinaison quelconque de dispositifs, à la seule condition que la somme d'indices d'équivalence de la sonnerie de tous les dispositifs n'excède pas 5.

AVERTISSEMENT

Pour assurer la sécurité, les utilisateurs doivent vérifier que la prise de terre du service d'électricité, les lignes télphoniques et les conduites d'eau métalliques sont connectées ensemble. Les utilisateurs NE doivent PAS tenter d'établir ces connexions eux-mêmes, mais doivent contacter les services d'inspection d'installations électriques appropriés ou un électricien. Ceci peut être particulièrement important en régions rurales.

UL Notice

This unit requires an AC adapter to operate. Use only UL Listed Class 2 Adapters with an output rating of 19 VDC, with a current of 4.22 A.

AC Adapter output polarity:





The modem-to-telephone network connection must be a line cord using a minimum #26 AWG wire.

For Authorized Repair Technicians Only

WARNING

- For continued protection against risk of fire, replace only with the same type and rating fuse.
- Danger of explosion if Lithium (clock) battery is incorrectly replaced. Replace only with the same or equivalent type recommended by the manufacturer. Dispose of used batteries according to the manufacturer's instruction.

LifeBook C Series Notebook

9 Glossary

LifeBook C Series Notebook - Section Nine

Glossary

1394

A fast external bus that allows transfer rates of up to 400 Mbps.

AC Adapter

A device which converts the AC voltage from a wall outlet to the DC voltage needed to power your LifeBook notebook.

ACPI

A power management specification that allows the operating system to determine the amount of power given to each connected device.

Active-Matrix Display

A type of technology for making flat-panel displays which has a transistor or similar device for every pixel on the screen.

ADSL

Asymmetric Digital Subscriber Line

Technology for transporting high bit-rate services over ordinary phone lines.

AGP

Accelerated Graphics Port. High-performance, component-level interconnect that enhances 3D graphical display.

APM

Advanced Power Management.

Auto/Airline Adapter

A device which converts the DC voltage from an automobile cigarette lighter or aircraft DC power outlet to the DC voltage needed to power your LifeBook notebook.

BIOS

Basic Input-Output System. A program and set of default parameters stored in ROM which tests and operates your LifeBook notebook when you turn it on until it loads your installed operating system from disk. Information from the BIOS is transferred to the installed operating system to provide it with information on the configuration and status of the hardware.

Bit

An abbreviation for binary digit. A single piece of information which is either a one (1) or a zero (0).

bps

An abbreviation for bits per second. Used to describe data transfer rates.

Boot

To start-up a computer and load its operating system from disc, ROM or other storage media into RAM.

Bus

An electrical circuit which passes data between the CPU and the sub-assemblies inside your LifeBook notebook.

Byte

8 bits of parallel binary information.

Cache Memory

A block of memory built into the micro-processor which is much faster to access than your system RAM and used in specially structured ways to make your overall data handling time faster.

CardBus

A faster, 32-bit version of the PC Card interface which offers performance similar to the 32-bit PCI architecture.

CD-R

Compact disc - read. A CD-R disc allows you to record to it once, then play it repeatedly. CD-R's typically contain about 640MB of data.

CD-ROM

Compact disc read only memory. This is a form of digital data storage which is read optically with a laser rather than a magnetic head. A typical CD-ROM can contain about 640MB of data and is not subject to heads crashing into the surface and destroying the data when there is a failure nor to wear from reading.

CD-RW

Compact disc - read/write. A CD-RW disc allows you to record to it multiple times, then play it repeatedly. CD-RW's typically contain about 640MB of data.

CMOS RAM

Complementary metal oxide semiconductor random access memory. This is a technology for manufacturing random access memory which requires very low levels of power to operate.

COMM Port

Abbreviation for communication port. This is your serial interface connection.

Command

An instruction which you give your operating system. Example: run a particular application or format a floppy disk.

Configuration

The combination of hardware and software that makes up your system and how it is allocated for use.

CRT

Cathode Ray Tube. A display device which uses a beam of electronic particles striking a luminescent screen. It produces a visual image by varying the position and intensity of the beam.

Data

The information a system stores and processes.

DC

Direct current. A voltage or current that does not fluctuate periodically with time.

DDR

Double Data Rate. A new memory module design that allows data transfer between memory and the processor at a rate that is double the bus rate. Faster transfer enhances application and multimedia performance. DDR memory modules are typically used in high performance PCs.

Default Value

A pre programmed value to be used if you fail to set your own.

DIMM

Dual-in-line memory module.

disk

A spinning platter of magnetic data storage media. If the platter is very stiff it is a hard drive, if it is highly flexible it is a floppy disk, if it is a floppy disk in a hard housing with a shutter it is commonly called a diskette.

Disk Drive

The hardware which spins the disk and has the heads and control circuitry for reading and writing the data on the disk.

Diskette

A floppy disk in a hard housing with a shutter.

DMA

Direct Memory Access. Special circuitry for memory to memory transfers of data which do not require CPU action.

DMI

Desktop Management Interface. A standard that provides PC management applications with a common method of locally or remotely querying and configuring PC computer systems, hardware and software components, and peripherals.

DOS

Disk Operating System (MS-DOS is a Microsoft Disk Operating System).

Driver

A computer program which converts application and operating system commands to external devices into the exact form required by a specific brand and model of device in order to produce the desired results from that particular equipment.

DVD

Digital Video Disc. A type of CD-ROM that holds up to 4.7GB of data, enough for a full-length movie. DVDs are backward-compatible with CD-ROMs, so that DVD

players can play old CD-ROMs, video CDs, and new DVD-ROMs.

DVD-R

Digital Video Disc - Readable. DVD-R discs can be written to only once, then read. DVD-R discs hold up to 4.7GB of data.

DVD-RW

DVD Read-Write. DVD-RW allows you to edit home movies. DVD-RW discs are designed to be compatible with existing players and drives. Discs are recordable over 1,000 times, and hold up to 4.7GB of data.

ECP

Extended Capability Port. A set of standards for high speed data communication and interconnection between electronic devices.

ESD

Electro-Static Discharge. The sudden discharge of electricity from a static charge which has built-up slowly. Example: the shock you get from a doorknob on a dry day or the sparks you get from brushing hair on a dry day.

Extended Memory

All memory more than the 640KB recognized by MS-DOS as system memory.

FCC

Federal Communication Commission.

Floppy Disk

A spinning platter of magnetic data storage media which is highly flexible.

FSA

Fujitsu Service Assistant. An interactive support tool that provides automated diagnosis and solutions for hardware and software problems.

GB

Gigabyte.

Hard drive

A spinning platter of magnetic data storage media where the platter is very stiff.

Hexadecimal

A decimal notation for the value of a 4 bit binary number. (0-9, A, B, C, D, E, F) Example: 2F in hexadecimal = 00101111 in binary = 47 in decimal.

I/O

Input/Output. Data entering and leaving your LifeBook notebook in electronic form.

I/O Port

The connector and associated control circuits for data entering and leaving your LifeBook notebook in electronic form.

IDE

Intelligent Drive Electronics. A type of control interface for a hard drive which is inside the hard drive unit.

IRQ

Interrupt Request. An acronym for the hardware signal to the CPU that an external event has occurred which needs to be processed.

ΚB

Kilobyte.

LAN

Local Area Network. An interconnection of computers and peripherals within a single limited geographic location which can pass programs and data amongst themselves.

LCD

Liquid Crystal Display. A type of display which makes images by controlling the orientation of crystals in a crystalline liquid.

Lithium ion Battery

A type of rechargeable battery which has a high powertime life for its size and is not subject to the memory effect as Nickel Cadmium batteries.

LPT Port

Line Printer Port. A way of referring to parallel interface ports. Historically line printers were the first and later the most common device connected to parallel ports.

MB

Megabyte.

Megahertz

1,000,000 cycles per second.

Memory

A repository for data and applications which is readily accessible to your LifeBook notebook CPU.

Memory Stick

Memory Stick is a flash memory technology developed by Sony Electronics. Memory Stick allows you to record, transfer and share digital content, such as still and moving images, music, voice, and computer data and applications.

MHz

Megahertz.

MIDI

Musical Instrument Digital Interface. A standard communication protocol for exchange of information between computers and sound producers such as synthesizers.

Modem

A contraction for MOdulator-DEModulator. The equipment which connects a computer or other data terminal to a communication line.

Monaural

A system using one channel to process sound from all sources.

MPU-401

A standard for MIDI interfaces and connectors.

NTSC

National TV Standards Commission. The standard for TV broadcast and reception for the USA.

Operating System

A group of control programs that convert application commands, including driver programs, into the exact form required by a specific brand and model of microprocessor in order to produce the desired results from that particular equipment.

Parallel Port

A connection to another device through which data is transferred as a block of bits simultaneously with a wire for each bit in the block and with other wires only for control of the device not for transfer of data.

Partition

A block of space on a hard drive which is set aside and made to appear to the operating system as if it were a separate disk, and addressed by the operating system accordingly.

PCMCIA

PCMCIA is a trademark of the Personal Computer Memory Card International Association. The Personal Computer Memory Card International Association is an organization that sets standards for add-in cards for personal computers.

Peripheral Device

A piece of equipment which performs a specific function associated with but not integral to a computer. Examples: a printer, a modem, a CD-ROM.

Pitch (keyboard)

The distance between the centers of the letter keys of a keyboard.

Pixel

The smallest element of a display, a dot of color on your display screen. The more pixels per area the clearer your image will appear.

POST

Power On Self Test. A program which is part of the BIOS which checks the configuration and operating condition of your hardware whenever power is applied to your LifeBook notebook. Status and error messages may be displayed before the operating system is loaded. If the self test detects failures that are so serious that operation can not continue, the operating system will not be loaded.

PPPoE

Point to Point Protocol over Ethernet.

A protocol for Ethernet, using a Point-to-Point Protocol (PPP), which is used for connection on the phone line.

Program

An integrated set of coded commands to your computers telling your hardware what to do and how and when to do it.

RAM

Random Access Memory. A hardware component of your LifeBook notebook that holds binary information (both program and data) as long as it has the proper power applied to it.

RAM Module

A printed circuit card with memory and associated circuitry which allows the user to add additional memory to the computer without special tools.

Reset

The act of reloading the operating system. A reset erases all information stored in RAM.

Restart

See Reset.

Resume

To proceed after interruption. In your LifeBook notebook this refers to returning to active operation after having been in one of the suspension states.

ROM

Read Only Memory. A form of memory in which information is stored by physically altering the material. Data stored in this way can not be changed by your LifeBook notebook and does not require power to maintain it.

SD

See Secure Digital.

SDRAM

Synchronous Dynamic Random Access Memory.

Secure Digital

A Secure Digital (SD) card is a small memory card that allows portable storage among a variety of devices, such as cell phones, GPS systems, digital cameras, and PDAs. SD cards transfer data quickly, with low battery consumption. Like the memory stick, it uses flash memory architecture. This means that a power source is not required to retain data.

Serial Port

A connection to another device through which data is transferred one bit at a time on a single wire with any other wires only for control of the device not for transfer of data.

Shadow RAM

A technique of copying data or applications stored in ROM (Read Only Memory) into RAM (Random Access Memory) for access during actual operation. RAM is much faster to access than ROM, however ROM contents are not lost when power is removed. Shadowing allows permanently stored information to be rapidly accessed.

SPDIF

Sony Philips Digital Interface Format. The optical digital audio format that allows you to download digital audio onto a MiniDisc recorder or connect to your sound system to play MP3 files with high fidelity sound.

SRAM

Static random access memory. A specific technology of making RAM which does not require periodic data refreshing.

SSID

Service Set Identifier

Specifies which network you are joining. Some systems allow you to specify any SSID as an option so you can join any network.

Status Indicator

A display which reports the condition of some portion of your hardware. On your LifeBook notebook this is an LCD screen just above the keyboard.

Stereo (audio)

A system using two channels to process sound from two different sources.

Stroke (keyboard)

The amount of travel of a key when it is pressed from resting to fully depressed.

Suspend

To make inoperative for a period of time. Your LifeBook notebook uses various suspension states to reduce power consumption and prolong the charge of your battery.

SVGA

Super VGA. Standard that provides 800x600 pixel resolution and a palette of 16M colors.

S-Video

Super Video. A component video system for driving a TV or computer monitor.

System Clock

An oscillator of fixed precise frequency which synchronizes the operation of the system and is counted to provide time of day and date.

TFT

Thin Film Transistor – A technology for flat display panels which uses a thin film matrix of transistors to control each pixel of the display screen individually.

UL

Underwriters Laboratories – An independent organization that tests and certifies the electrical safety of devices.

UMA

Unified Memory Architecture. A computer architecture that uses graphics chips on the motherboard that use part of the main memory for video memory.

USB

Universal Serial Bus. The USB 2.0 specification is a peripheral bus standard for connecting external devices at up to 480Mbps. Some features of the standard include support for up to 127 concurrent USB devices, dynamic insertion and removal of devices, and self-identifying peripheral configuration for true plug-and-play functionality. USB 1.0 connects external devices at up to 11Mbps. USB 2.0 is backward-compatiblewith USB 1.0 devices to allow you to connect older devices to the ports.

VGA

Video Graphics Array. A video display standard originally introduced by IBM with the PS/2 series of personal computers. Provides resolutions of 720 x 400.

VRAM

Video Random Access Memory. A memory dedicated to video display data and control.

WEP

Wired Equivalent Privacy

WEP is a protocol for increasing privacy over wireless LANs. The protocol works by encrypting data while being transmitted over radio waves.

Wi-Fi Compatible

Wi-Fi (Wireless Fidelity) Identifies that the product has passed the interoperability test, supplied by the WECA (Wireless Ethernet Compatibility Alliance), which guarantees the interoperability of wireless IEEE 802.11 LAN products. For more information on the Wi-Fi standard, go to the WECA website at: www.wirelessethernet.com.

WFM

Wired for Management is Intel's broad-based initiative to reduce the total cost of ownership (TCO) of business computing without sacrificing power and flexibility.

Write Protect

Prevent alteration of the binary state of all bits in a storage media. Example: all information on a device such as a floppy diskette; a block of space in a storage media such as a partition of a hard drive; a file or directory of floppy diskette or hard drive.

XGA

Extended graphics array. Standard that provides resolutions of 640x480 or 1024x764, supporting 64k colors.

LifeBook C Series Notebook - Section Nine

Index	D
	DC Output Cable25
A	DC Power Jack9, 25
AC	DIMM45
adapter 25 indicator 13 plug adapters 85	Disk
Anti-theft Lock Slot	* '
Auto Insert Notification	Display Panel
Auto/Airline Adapter	brightness
В	opening
Battery	Display Panel Latch8
care	Display Timeout31
charging indicator	Dolby Headphone
conserving power 30 dead 76	Double-Clicking
faulty	Dragging19
increasing life	Drivers and Application CD82
lithium ion battery	E
low	Emergency Media Player Tray Release10
recharging	Error Messages80
replacing	Extended Memory102
suspend mode	External Floppy Disk Drive access indicator
Guide	External Monitor Port48
Boot	F
Boot Sequence	Floppy Disk
Built-in Speakers	ejecting
C	initializing
Cache Memory	preparing
CapsLock Indicator	write protect
Click Me!	Floppy Disk Drive
Clicking	care
COMM Port	Fujitsu LifeBook storing85
Configuration Label	traveling
Control	Fujitsu PC Contact Information
Conventions Used in the Guide	Fujitsu Service Assistant
	Function Key
Cursor	F1016
Cursor Keys	

F3	loading .39 removing .39 Software .38, 39 using .40
F7	Media player care
G	Media Player Eject Button10
Glossary 101	Memory
H Hard Disk Drive	capacity .46 extended .46 installing .45 removing .46
access indicator	system
Hard Disk Timeout	Memory Stick
Headphone Jack	installing42
Hibernation (Save-to-Disk) Mode	Memory Upgrade Module
I	Microphone Jack47
•	Modem Jack
IEEE 1394 Port	Modem Result Codes81
Infrared Port	mouse
Installing	
Installing a Memory Stick 42	N
Internal	Numeric Keypad15
Internal Floppy Disk Drive	NumLk Indicator14
Internal LAN Jack	_
IrDA	Р
V	Parallel Port
K Keyboard	PC Card .75 access indicator .14 care .87
function keys	PC Card Slots9
numeric keypad	PC Cards removing
L	Pointing
LifeBook	ports
LifeBook Application Panel 8	POST103
control panel	Power
locking/unlocking selector switch 20, 21	AC adapter
M	failure
Media Player 10 access indicator 14	off
care	power

Index

Power Management	Т
Pre-Installed Software 93 manuals 93 McAfee.com ActiveShield 93	Touchpad 18 buttons 18 controls 19
R	Touchpad Pointing Device8
Registration	Troubleshooting
Removing a Memory Stick	troubleshooting
Restarting	U
RJ-11 47	Universal Serial Bus Port
RJ-45	Upgrade
•	USB
S	Using the Media Player
Save-to-Disk Mode	,
ScrLk Indicator	V
SD Card removing	Volume Control
SDRAM	W
Secure Digital Card removing	Warranty Information
Serial Port	Start keys
Shut Down	Windows Product Activation
Software	Wireless LAN About IP Addresses
Specifications	
Standby Mode	
Status Indicator Panel	
Status LCD Panel	
Stereo Line-in Jack	
Stereo Speakers 8	
Suspend	
Suspend Mode	
Suspend/Resume Button	
S-Video Out Port	